


Model TANK Fire Suppression Extinguishing System Installation, Operation, and Maintenance Manual



TANK Fire Suppression Extinguishing System Typical Hood End Cabinet Installation

RECEIVING AND INSPECTION

Check for any signs of damage upon receipt, and if found, report it immediately to the carrier. Check that all items are accounted for and free of damage.

WARNING!

The TANK Fire Suppression extinguishing system unit is to be installed, inspected, recharged and maintained in accordance with NFPA 17A, NFPA 96, and the National Fire Code of Canada as applicable.

Installation and maintenance of the TANK Fire Suppression extinguishing system must be performed in accordance with this manual by a factory trained distributor. Improper installation poses serious risk of injury due to electric shock and other potential hazards. Read this manual thoroughly before installing or servicing this equipment. **ALWAYS** disconnect power prior to working on equipment.

Save these instructions. This document is the property of the owner of this equipment and is required for future maintenance. Leave this document with the owner when installation or service is complete.



WARNING!

Read and Understand the Operator's Manual before servicing this unit. This Quick Start Guide is for Trained and Qualified Fire System Technicians.

HMI, ECPM03, and CORE Board

The HMI provides access to change settings, view operating information, and displays faults (Figure 1) for the electrical package, exhaust fan, and fire system. The HMI has 4 buttons; the function is displayed adjacent to each button on the screen. For more information on menu navigation, refer to the Demand Control Ventilation (DCV) Manual.




Figure 1 (HMI Screen Example)

The ECPM03 also provides access to fire system information. You can view Faults and Last Fire Info. You may also view if the fire system was activated by Firestat or MAD (Manual Activation Device). The Board has 4 buttons; the function is displayed below each button near the LCD screen (Figure 2). For more information on the ECPM03 Board, refer to the DCV Manual.




Figure 2 (ECPM03 LCD Example)

The CORE Board uses LEDs (Figure 3) for alerts. The LED lamp meanings are:

- A is for Alarm Alerts
- B is for Fire System and/or Supervision Codes
- C is N/A
- D is for Gas Shut Down (Gas is off when the light is on).

Maintenance

WARNING: When servicing or cleaning ductwork, all Hood CORE, PCU CORE, and interlocked fire systems must be placed in test mode to prevent accidental discharge.

- Verify that the system design and installation are adequate to protect the hazard area and conform to the instructions in the Operation, Installation, and Maintenance (OIM) Manual.
- Hood filters must be maintained on a daily basis to ensure proper airflow and grease extraction. Clean filters per the recommendations in the Hood Installation, Operation, and Maintenance Manual.
- All actuation hoses must be hydrostatically tested (at 500 psi test pressure) or replaced every twelve years in accordance with NFPA 17A.
- Refer to the TANK Maintenance section for 6-Month Inspection Procedure.
- Every two years, you must replace the batteries and inspect all electrical wiring and piping.
- If it should become necessary to disconnect the TANK system from AC power for an extended period of time (more than two days), the batteries should be disconnected to prevent them from being damaged due to complete discharge.
- After a fire; Inspect and/or replace all nozzles, Inspect all piping connections for tightness, Inspect all hood lights for proper seal and security, Inspect all wiring and Hood insulation to ensure all are in good condition.
- Tanks must be replaced every twelve years.




Figure 3 (CORE Board Example)

NOTE: See TANK Operation, Installation, and Maintenance Manual for detailed procedures.

Failure to properly maintain equipment will void warranty.

To order Batteries,
Scan the QR Code:



When there are no faults in the fire system, Lamp B will stay solid (An LED indicator, labeled as Fire System Status, is also on the control package). When a fault exists, the LED will flash with a short break. Count the flashes then wait for a short break to determine the fault. For packages with HMIs, refer to the fault displayed on the screen.

NOTE: CORE Boards with software versions 1.68 and prior will use one brief flash every 3-seconds to indicate there is no fault.

Test Mode allows the system to be tested with operational appliances without discharging the system. If the system is left in test mode for 15 minutes, the gas valve will be locked out until test mode is deactivated.

Flashes	Fault Condition	Corrective Action
Catastrophic Faults		
1	Invalid Activation*	Check for external voltage being applied at J3-7 and J3-10.
2	Release Solenoid*	Check solenoid and wiring to solenoid, replace as needed.
3	Pressure Switch*	Check switch and wiring to switch, replace as needed.
4	N/A	N/A
5	Microcontroller Fault*	Replace CORE printed circuit board.
Critical Faults		
6	N/A	N/A
7	Supervised Loop Fault*	Check the installation of the wiring to all the manual actuation devices (push stations) and firestats. Verify connections are secure and tight. Check for open/short circuits in the wiring. Repair or replace wiring as needed.
Important Faults		
8	Ground Fault	Check the installation of the wiring to all the manual actuation devices (push stations) and firestats. Verify connections are secure and tight. Check for open/short circuits in the wiring. Repair or replace wiring as needed.
9	N/A	N/A
10	Battery Voltage Low	The voltage is below the battery threshold. Wait for batteries to recharge if there was a power failure. Replace if the batteries will not hold a charge.
11	AC Power Failure*	The voltage is below the power supply (PS-02) threshold; approximately 27.18V DC. Check breakers, call power company.
12	Door Tamper Switch	Close cabinet door.
13	Test Mode*	Place switch in armed position when testing is complete.
14	CORE Interlock	Check Dip Switches on all boards and RS-485 network wires connecting boards.
15	Fault on Hood in Network	Check all hoods in CORE network for faults.
16	Fault on PCU in Network	Check all PCUs in CORE network for faults.

NOTE: The low pressure switch option is not required per product safety listings and standards. The fault is for monitoring purposes. When a Pressure Switch or Supervised Loop fault is present for 24 hours, cooking operations will shut down.

Faults marked with (*) will shut down Gas/Shunt. During an AC power failure or loss of building power, all 120V AC gas valves/electrical appliances will shut down immediately. For 24V DC gas valves, the valve will stay powered for a few minutes depending on battery voltage (when both an AC Power Failure and Battery Voltage Low fault are present, the valve will shut down).

Start-up and checks must be performed after install. Warranty will be void without completion of forms. Scan or print these pages during installation or inspection procedures.

Job Information:

Start Date/Time		Type of Inspection: (check mark one)	Commissioning	Semi-Annual
Business Name:				
Business Address:			Startup after Decommissioning (For systems shutdown for over 2-days)	
Business Phone:				

Cooking Appliance Locations: Left to Right

--

Name Plate and Hood Information					
Fire System #	Hood Model #	Job #	Volts	Hertz	Phase

TANK System Verification

Verify all nozzles are secure		Actuators in Ship/Test Position (First Install/Semi Annual Inspections)	
Check field piping is complete with approved materials		Vent limiting orifice is installed in last actuator	
Multiple hood connections: Check supply line connections are complete		Pressure gauge monitoring performed (Nitrogen to PAK Hose)	
All appliances properly covered with correct nozzles; Verify correct flows (4FP, 5FP, 6FP) are covering the proper appliance		No pressure leaks in the manifold. Verify Pro Press fittings are secure. Nitrogen is not leaking through	
		PAK Hose connected and torqued to 15 in-lbs	
Duct and Plenum covered with correct nozzles		Pressure gauge leakage test	
Tank cylinders have proper PSI with gauges functioning properly. Pressure is in the green range		System connections sprayed with coil leak detector	
Tanks installed securely with straps and mounting hardware		All filters are installed	
O-ring is installed, and free of damage, in Primary Actuator Hose (PAK Assembly)		Verify gas valve strainer is installed. Clean out strainer (Gas must be shut off)	

Service Notes:

TANK Fire Suppression: Inspection Report

Electrical		Low Voltage Wiring		Fire System	
TANK Control Panel power wired (Wall Mounted Control cabinet only)		All Firestats are wired		Record Battery Date Code	
Power Supply PS-02 is connected to AC power		Remote Push Station is wired		Record CORE Board Revision #	
Verify all fans are wired to control panel and operate		Supervised loop is run through metallic conduit and not with high voltage wiring		Push station cover and tamper seal installed	
Shunt Trip Breaker wired (if required)		Supervised loop connections secured in terminal blocks, j-boxes, and push-station(s)		All nozzles are 35-50" from Hazard Zone Nozzles within 18" from Front/Back of Hazard Zone	
UDS Appliance Kill Switch (if equipped) wired		Building alarm and trouble relay wired (if required)		Check dedicated appliance coverage (if required)	
Gas valve wired (if 120V AC) = Terminals GAS and N1		Battery connected at connector J1		Record Power Supply (PS-02) output voltage	
		Gas valve wired (if 24V DC) = Terminals LGV and N1D		Verify all CORE Board interlocks are connected (CA, CB, CC)	
		Secondary Release solenoid valve wired (Remote cabinet only) and Pressure switch		After testing is complete, the actuator(s) are mounted to the tank(s)	

Fire System Activation Method	
Manual Activation Device (MAD)	
Firestat	
120V AC Only	
Battery Backup Only	
"Push to Reset" operates	

Fire Mode	
Release solenoid opens and balloons inflated	
All gas and electric appliances shutdown	
Fire system light activates	
Audible alarm sounds	
Actuators deployed (Ship/Test Position)	
HMI displays "FIRE"	

ALL SYSTEMS MUST BE ARMED AND NO FAULTS SHOULD BE PRESENT BEFORE LEAVING THE SITE. YOU MUST VERIFY THE ACTUATORS ARE MOUNTED TO THE TANKS BEFORE LEAVING THE SITE!

Service Contact Information:

End Date/Time	
Service Company:	
Company Address:	
Company Phone:	
Contact Name (Printed):	
Contact Name (Signed):	

Service Notes:

Table of Contents

TANK Fire Protection: Quick Start Guide	3	Test Mode Overview	56
TANK Fire Suppression: Inspection Report	5	Reset Overview	56
TANK Fire Suppression: Inspection Report	6	Battery Backup	57
WARRANTY	8	Power Supply Adjustment	57
CERTIFICATIONS	8	Fire Protection System Firestat	58
SYSTEM OVERVIEW	8	Non-Solid Fuel Hood/Appliances (Rated 450°F)	58
COMPONENTS	9	Non-Solid Fuel Hood/Appliances (Rated 600°F)	58
Cylinder Tank Assembly	10	Solid Fuel Hood/Appliances (Rated 700°F)	58
Cylinder Tank and Actuator Bracket	11	TROUBLESHOOTING	59
Discharge Adapter	11	CORE Board Faults	60
Nozzles	12	Appliance Shutdown in Fault Conditions	61
Primary Actuator Kit (PAK)	12	Local Alarm Muting	61
Secondary Valve Actuator (SVA) and Hose	13	Test Mode	61
Supervisory Pressure Switch	13	Supervised Loop/Power Supply Troubleshooting	62
Gas Shut-Off Valves	14	DIP Switch Settings	63
Electric Remote Manual Release	14	START-UP/INSPECTION TEST PROCEDURE	65
Firestat (Heat) Detector	14	Fire System Wiring Connections	65
INSTALLATION	15	Preparing System for Test	65
Cylinder Tanks	15	Connecting Service Test Kit	66
Removing Full Cylinder Tanks (Optional)	16	Balloon Test Procedure	68
Primary and Secondary Actuator Installation	16	Firestat Test Procedure	69
Primary Actuator Kit (PAK)	17	Disconnecting Service Cylinder Tank	69
Secondary Valve Actuator (SVA)	17	Re-arming System	69
Supervisory Pressure Switch	18	Leakage Testing	70
Wall-Mount Utility Cabinet (WMUC) Installation	19	Every Month (System Owner)	71
WMUC Installation with Hanging Angles	19	Every Six Months (Factory Trained Distributor)	72
WMUC Wall-Mount Option	19	Every Two Years	72
Duct and Plenum Protection	20	Every Twelve Years	72
Plenum Protection	20	Decommissioning	72
Duct Protection	21	Agent Cylinder Tanks	72
Ventilation Exhaust and Dampers	23	Actuation Hoses	72
Electrostatic Precipitators (ESP)	23	Conditional Maintenance	73
Appliance Protection	24	Replacing A Primary Actuation Kit	73
Overlapping Appliance Protection	24	Replacing A Secondary Valve Actuator	73
Appliance Coverage	25	Adding Nitrogen to Tank(s)	74
Other Appliance Coverage	27	POST-DISCHARGE MAINTENANCE	75
Overlapping Protection	28	General Information	75
Overlapping Coverage - Group Protection	28	Appliance Cleanup	75
Upright Broiler/Salamander Protection	30	Cleaning Distribution System	75
Appliance with Shelf	31	Cleaning Nozzles	75
Wok Protection	32	Flushing the Distribution Pipe Network	76
Large Wok Protection	33	Flushing Procedure with Spare/Test Cylinder	76
Overhead Obstruction/Salamander Protection	34	Flushing Procedure with an External Water Supply	77
Pizza Ovens	35	Flush the System	77
Agent Distribution Piping	37	Dry the Lines	78
Cylinder Nozzle and Piping Parameters	39	Cylinder Tank Maintenance	79
Nozzle Installation	39	Removing a Cylinder Tank (Empty or Storage)	79
Gas Shut-Off Valves	40	Installing New Cylinder Tank(s)	80
Gas Valve Orientation	41	Depressurizing a Cylinder Tank	81
Hood Riser Sensor Replacement	43	Rechecking the System	81
Fire Protection Manual Actuation Device	44	Mobile Kitchen/Seasonal Shutdown	82
Trouble Input Wiring	44	TANK FIRE SUPPRESSION SYSTEM PARTS	83
Fire Protection System Printed Circuit Board	45	CLEANING AND MAINTENANCE RECORD	84
Electrical	48	Technical Support Information	84
Wire Ampacity Rating	49		
Distance Limitations	49		
Fire Alarm Contacts	49		
Fire Group	50		
Fire Protection System Supervised Loops	51		
Supervised Loop Electrical Details	52		
PCU Fire System	53		
PCU Fire System Nozzles	54		
OPERATION	55		

WARRANTY

Model TANK Fire Suppression extinguishing system is warranted to be free from defects in materials and workmanship, under normal use and service, for a period of 60-months from date of shipment. Warranty does not cover consumable products such as batteries and nitrogen. This warranty is null and void if:

1. The system is not installed by a factory trained installer per the MANUFACTURER'S installation instructions shipped with the product.
2. The equipment is not installed in accordance with Federal, State, Local codes, and regulations.
3. The system is misused or neglected, or not maintained per the MANUFACTURER'S maintenance instructions.
4. The system is not installed and operated within the limitations set forth in this manual.
5. The invoice is not paid within the terms of the sales agreement.

The MANUFACTURER shall not be liable for incidental and consequential losses and damages potentially attributable to malfunctioning equipment. Should any part of the equipment prove to be defective in material or workmanship within the 60-month warranty period, upon examination by the MANUFACTURER, such part will be repaired or replaced by MANUFACTURER at no charge. The BUYER shall pay all labor costs incurred in connection with such repair or replacement. Equipment shall not be returned without MANUFACTURER'S prior authorization, and all returned equipment shall be shipped by the BUYER, freight prepaid to a destination determined by the MANUFACTURER.

CERTIFICATIONS

The Tank Fire Suppression system is ETL Listed in accordance with ANSI/CAN/UL/ULC 300, ULCORD-C1254.6.

The microprocessor-based control board is ETL Listed to UL Standard 864 and CAN/ULC-S527-11.

The Tank Fire Suppression system is acceptable for use in New York City, and is approved per FDNY COA #5870.

SYSTEM OVERVIEW

The Tank Fire Suppression extinguishing system provides fire protection for commercial cooking appliances and ventilation. The Tank Fire Suppression extinguishing system is electrically released via a 24V DC solenoid valve. Extinguishing system units with electrical detection, activation, and control require the use of a Listed Control Panel, which has been found acceptable for releasing device service and which is compatible with the electrical actuators used on the extinguishing system. In addition, all electrical detectors, notification devices, and push stations are required to be Listed and compatible with the Control Panel.

COMPONENTS

The following section lists the major components used in the TANK Fire Suppression extinguishing system.

Figure 1 - Shipping/Test View

1. Unit is shown in Shipping/Test Position
2. Tank Straps
3. Tank Mounting Bracket (Secured to cabinet with rivets)
4. Cylinder Tanks (Up to four tanks may be installed depending on cabinet size.)





Figure 2 - Exploded View

1. Tank Mounting Brackets
2. Secondary Supervisory Pressure Switch (Optional)
3. Secondary Cylinder (Optional)
4. Primary Cylinder
5. Supervisory Pressure Switch
6. Primary Actuator Kit
7. Secondary Actuator Hose (Optional)
8. Secondary Valve Actuator (Optional)
9. Primary Valve with Siphon Tube
10. Secondary Valve with Siphon Tube (Optional)

Tank straps not shown.




NOTE: Tanks should never be filled with agent in the field.

Cylinder Tank Assembly

The TANK Fire Suppression cylinder assembly (p/n 87-300001-001) uses a mild steel cylinder, conforming to 4BW250 DOT & 4BWM-17 TC specifications, and a nickel-plated brass valve with pressure indicator gauge. Each valve includes a Schrader valve for connection to the primary actuator hose (for primary cylinders) or the supervisory pressure switch (optional for secondary cylinders).

Each cylinder assembly is factory-filled with TANK liquid fire suppressant and pressurized to 200 psig (1379 kPa) at 70°F (21°C). Each cylinder supports up to 5 nozzles for a total of 20 flow points.


Figure 3 - Cylinder Tank Details



The pressure of a cylinder will vary with the ambient temperature, as detailed in **Table 1**. The gauge indicator (shown in **Figure 3**) should be in the acceptable 'green' range for a cylinder that is properly pressurized and within the listed operating temperature range. For a cylinder at the lowest listed operating temperature of 32°F (0°C), the pressure gauge should read approximately 175 psig (the lower end of the green range). For a cylinder at the highest listed operating temperature of 130°F (54.4°C), the pressure gauge should read approximately 225 psig (the upper end of the green range).

NOTE: The agent itself may be stored down to -20°F (not operational system temperature).

Table 1 - Cylinder Temperature Vs Pressure




Cylinder Tank and Actuator Bracket

Each cylinder assembly is secured to a factory-installed cylinder bracket in the cabinet (p/n TFS-UCTANKBRACKET). The cylinder is secured to the cylinder bracket via three (3) stainless steel straps.

The cylinder bracket also includes a platform for securing a primary actuator kit or secondary valve actuator during shipping and maintenance procedures.

Figure 4 - Cylinder Tank and Actuator Bracket




Discharge Adapter

The discharge adapter (p/n WK-283952-000) is used to connect the TANK Fire Suppression cylinder valve outlet to the agent distribution pipe network. The 1/2-inch NPT internal thread of the discharge adapter outlet is connected to the supply line via an elbow and adapter.

The discharge adapter uses an O-ring (p/n WK-108019-000) at the valve port to eliminate leaks during discharge.


Figure 5 - Discharge Adapter



Nozzles

The Overlapping Female Nozzle(s) (p/n OL-F) are used for plenum, duct, overlapping appliance protection, and dedicated appliance coverage (e.g., salamanders, upright broilers, chain broilers, and appliance with upright obstructions). The nozzles include a cap (p/n 3074-1-1). The cap prevents contamination from entering the pipe network and is designed to pop-off upon system discharge, allowing the agent to flow to the protected hazard area. Refer to **“Duct and Plenum Protection” on page 20.**

Figure 6 - Fire System Nozzle



Primary Actuator Kit (PAK)

The Primary Actuator Kit (PAK) (p/n 87-300030-001) is installed on each primary cylinder assembly to pneumatically open the cylinder valve and provide actuation pressure for up to three secondary valve actuators. A vent limiting orifice is present to allow easier resetting of SVA pistons during inspections.


The PAK consists of a pneumatic actuator, 24V DC solenoid valve, solenoid strainer (recommended by the manufacturer), check valve, primary actuator hose, and associated fittings.

When activated, through automatic or manual system actuation, the control panel sends a momentary 24V DC release signal. The solenoid strainer will filter out debris from entering the system. The PAK solenoid will open, allowing pressure from the primary cylinder to pass through the solenoid and check valve. The pressure flows into the primary actuator (actuating the primary cylinder), and into the interconnected secondary valve actuators (actuating the secondary cylinders).

The primary actuator has a 1/8" NPT inlet port for connection to the primary system cylinder, and a 1/8" NPT outlet port for connection to the secondary cylinder actuation line or actuation line vent limiting orifice for single cylinder system. The primary actuator includes a piston with a spring-loaded locking pin which locks the piston in the discharge position, ensuring complete discharge of the cylinder contents. When testing/inspecting, if a component fails inspection, replace the PAK assembly.

Figure 7 - Primary Actuator Kit

1. Schrader Service Valve
2. Check Valve
3. Solenoid Valve
4. Supervisory Pressure Switch Connection
5. Solenoid Strainer (internal to assembly)
6. Knurled Fitting
7. Primary Actuator
8. Primary Actuator Hose (Stainless Steel)
9. Locking Pin
10. Piston
11. Hex Fitting
12. Vent Limiting Orifice




NOTE: The primary supervisory pressure switch is standard on primary tanks. Secondary supervisory pressure switches are optional on secondary tanks.

Secondary Valve Actuator (SVA) and Hose

A Secondary Valve Actuator (SVA) (p/n 87-120042-001) is installed on each secondary cylinder assembly to pneumatically open the cylinder valve(s). The SVA has 1/8" NPT inlet and outlet ports for connection to the system actuation line via the SVA hose. All secondary hoses require a 1" minimum bend radius. The SVA includes a spring-loaded locking pin that locks the actuator piston in the discharge position, ensuring complete discharge of the cylinder contents.

Figure 8 - Secondary Valve Actuator




Supervisory Pressure Switch

The primary and (optional) secondary supervisory pressure switch (p/n 87-300040-001) are preset to alarm at a cylinder pressure of ~10% below the lowest operating system pressure of 175 psig (pressure at the lowest listed operation temperature of 32°F). The supervisory pressure switch uses a diaphragm sensor to detect pressure changes. At the predetermined set point, the unit actuates a SPDT snap-acting switch, converting a pressure signal into an electrical signal. The supervisory pressure switch can be used on primary and/or secondary cylinders. For primary cylinders, the pressure switch is mounted on the primary actuator kit. For secondary cylinders, the pressure switch is mounted on the Schrader fitting installed on the cylinder valve.

Figure 9 - Supervisory Pressure Switch

- 1. Supervisory Pressure Switch (Primary)
- 2. Wrench Flats
- 3. Secondary Supervisory Pressure Switch (Optional)
- 4. Schrader Valve



Gas Shut-Off Valves

Electric gas shut-off valves are used to shut down the flow of fuel gas to the kitchen appliances upon actuation of the TANK Fire Suppression system. An energized solenoid is used to hold the gas valve in the open position. The solenoid closes the valve when de-energized via the output relay of the control panel. The gas valves are available in 120V AC and 24V DC, ranging from 3/4" to 3" pipe sizes. Refer to **"Gas Shut-Off Valves"** on page 40 for more information.


Electric Remote Manual Release

An electrically operated manual release that is listed must be used with the TANK Fire Suppression extinguishing system. The electric remote manual release is used to actuate the TANK Fire Suppression extinguishing system manually and must be properly located and supervised in accordance with NFPA 17A and NFPA 96.

Firestat (Heat) Detector

The Firestat (Fenwal Detect-a-Fire) is a listed electric thermal detector available in a variety of temperature settings and used to actuate the TANK Fire Suppression extinguishing system automatically. When a Firestat senses a temperature higher than its setpoint, the Firestat contacts will close and energize the TANK Fire Suppression system via the control panel.

Figure 10 - Firestat



INSTALLATION

The extinguishing system consists of pressurized agent storage cylinders tanks, agent distribution piping, valve actuators, supervisory pressure switches, and agent discharge nozzles. All primary components and piping are factory-installed. Systems may be comprised of single or multiple cylinders depending on the size and configuration of the protected hazards.


Cylinders can be piped independently, or manifolded. On two-cylinder systems, the cylinders will be in a manifold configuration. Refer to “**Agent Distribution Piping**” on page 37 for a two-cylinder system example. On three-cylinder systems, two cylinders will be in a manifold configuration and one independent. On four-cylinder systems, there will be two separate manifolds.

In a fire condition or upon manual actuation, the solenoid valve is opened, allowing pressure from the primary cylinder to flow to the primary and secondary cylinder valve actuators, opening the cylinder valves and discharging liquid fire suppressant to the protected hazard areas.

WARNING!

System must be installed and operated in a conditioned space between 32°F and 130°F.

Figure 11 - Cylinder Assemblies




Cylinder Tanks

Cylinders are typically factory-installed, pressurized, and may be located anywhere within the hood end cabinet.

Additional cylinders may be field installed, as needed, in the additional hood end or wall mount cabinet. **Figure 12** shows a dual cylinder system mounted to the right of the hood control unit. Each cylinder assembly is secured to a factory-installed cylinder bracket in the hood end cabinet. The cylinder is secured to the cylinder bracket via three (3) stainless steel straps.

Figure 12 - Dual Cylinder Mounted in Cabinet



Right side cabinet mount shown.


Removing Full Cylinder Tanks (Optional)

When installing the hood, to reduce weight, you may remove the cylinder(s).

1. Verify the actuators are in the shipped position (**Figure 14**). If the system contains multiple tanks, check all additional actuators.
2. Use a 1/2" and 9/16" box end wrench to remove the two mounting bolts holding the tank on the bracket.
3. Loosen the straps.
4. Remove the tanks. Repeat for additional tanks.
5. Always reinstall tank(s) after the hood is secured. Refer to "Installing New Cylinder Tank(s)" on page 80.

NOTE: When tightening the tank straps, use zip ties to secure excess banding.

Figure 13 - Removing Full Cylinders




Primary and Secondary Actuator Installation

WARNING!

Do not complete PAK or secondary valve actuator installation until system test and commissioning are complete. The cylinder bracket includes a platform for securing a primary actuator kit or secondary valve actuator during shipping and maintenance procedures. The system actuators must be in the ship/test position for all commissioning and test procedures. Testing with actuators in place will result in discharge of the agent cylinders.

Refer to "START-UP/INSPECTION TEST PROCEDURE" on page 65 for the testing and commissioning unit.

Figure 14 - PAK in Ship/Test and Installed Positions




- | | |
|---------------------------|---|
| 1. Shipping Bolts | 4. Mounting Bolts |
| 2. Nut | 5. Primary Actuator Kit (In Transport Position) |
| 3. Valve Protection Plate | 6. Supervisory Pressure Switch |

Primary Actuator Kit (PAK)

The primary actuator kit is mounted to the primary cylinder bracket during shipment and when testing the system. With the cylinders securely mounted and connected to the system piping, the primary actuator kit can be installed onto the primary cylinder for the final setup.

1. Remove the valve protection plate and nuts. Retain the mounting bolts for installation of the PAK.
2. Ensure the primary actuator piston is in the set position.
3. Loosen the PAK shipping bolts from the top of the bracket, slide the unit back and lower it into position on the valve actuation flange.
4. Insert the mounting bolts through the bottom of the valve flange into the PAK mounting holes and tighten securely.
5. Connect the primary actuator hose to the Schrader valve on the primary cylinder valve. The primary hose requires a 1.5" minimum bend radius.

Figure 15 - Actuator Valve



1. Set Position
2. Actuated Position

WARNING!

Installation of the primary actuator hose is the FINAL step performed.

Connecting this hose earlier may result in accidental system discharge. Refer to "START-UP/ INSPECTION TEST PROCEDURE" on page 65 for the testing and commissioning procedure.

When inspecting the primary actuator hose, replace O-ring. Refer to "TANK FIRE SUPPRESSION SYSTEM PARTS" on page 83.

The primary and secondary actuation hoses cannot be interchanged. The primary actuation hose must be used with the PAK.

Secondary Valve Actuator (SVA)

With the cylinders securely mounted and connected to the system piping, the secondary valve actuators (SVA) can be installed onto each of the secondary cylinder(s).

1. Remove the valve protection plate and nuts. Retain the mounting bolts for installation of the SVA.
2. Loosen the SVA shipping bolts from the top of the bracket, slide the unit back and lower it into position on the valve actuation flange.
3. Insert the mounting bolts through the bottom of the valve flange into the SVA mounting holes and tighten securely.
4. Ensure the secondary actuator hose is securely connected to the primary actuator output port and SVA input port.

Key Limitations

- Total length of secondary actuation flex hose must not exceed 75" of flex hose. Refer to "**Secondary Valve Actuator (SVA) and Hose**" on page 13 for secondary hose information.
- Secondary actuator hose(s) require 1" minimum bend radius.
- Maximum number of secondary valve actuators operating from the primary actuator unit is three (3).

WARNING!

The Valve Protection Plate must remain on the valve actuation port until the valve actuator is installed.

The primary and secondary actuation hoses cannot be interchanged. The secondary actuation hose (7", 24" or 60" length) must be used with secondary valve actuators.


Supervisory Pressure Switch

A supervisory pressure switch will always be located on the primary cylinder by the Primary Actuator Kit (PAK). For secondary cylinders, this is an optional component that may be added on. For primary cylinders, the pressure switch is mounted on the primary actuator kit. For all secondary cylinders, the pressure switch is mounted on the Schrader fitting on the cylinder valve.

1. Remove cap from applicable Schrader fitting.
2. Thread the switch onto the Schrader using the brass wrench flats only.

Figure 16 - Supervisory Pressure Switch Installation

1. Supervisory Pressure Switch (Primary)
2. Wrench Flats
3. Schrader Valve
4. Optional Secondary Supervisory Pressure Switch



WARNING!

Proof pressure (*) limits stated on the nameplate must never be exceeded, even by surges in the system. Occasional operation of unit up to proof pressure is acceptable (e.g., start-up, testing). Continuous operation should not exceed the designated over range pressure ().**

***Proof pressure - the maximum pressure to which a pressure sensor may be occasionally subjected, which causes no permanent damage (e.g., start-up, testing).**

****Over Range Pressure - the maximum pressure to which a pressure sensor may be continuously subjected without causing damage and maintaining set point repeatability.**

NOTE: Pressure switches do not contain any field replaceable parts. Refer to applicable control panel manual for wiring of the supervisory pressure switch. Wire in accordance with local and national electrical codes.

WARNING!

Disconnect all supply circuits before wiring pressure switch. Electrical ratings stated in literature and on nameplate must not be exceeded - overload on a switch can cause failure on the first cycle.

The electrical rating is rated to 5A resistive and 3A inductive at 30V DC; gold flashing over silver contact for loads down to 1mA at 24V DC.

Wiring Color Code

Red
Black
White

Terminals

NO (NC under Pressure)
NC (NO under Pressure)
Com

Supervisory pressure switches are connected in series to the control panel supervisory input.

Wall-Mount Utility Cabinet (WMUC) Installation


WMUC Installation with Hanging Angles

The utility cabinet will be field installed by others. Refer to Utility Cabinet Schedule for cabinet size.

The hanging angle must be supported with 1/2"-13 TPI Grade 5 (minimum) All-Thread. Sandwich hanging angles and ceiling anchor points with 1/2" Grade 5 (minimum) steel flat washers and 1/2"-13 TPI Grade 5 (minimum) hex nuts. Refer to **Figure 17**. Hardware provided by others.

1. Must use doubled hex nut configuration beneath utility cabinet hanging angles and above ceiling anchors.
2. Maintain 1/4" of exposed threads beneath bottom hex nut.
3. Torque all hex nuts to 57 ft-lbs.

Figure 17 - Hanging Angle Mount Details



WMUC Wall-Mount Option


The utility cabinet will be field installed by others. Refer to Utility Cabinet Schedule for cabinet size.

The utility cabinet must be secured to the wall using a minimum of eight (8) fasteners and washers. Use four fasteners/washers on the top of the cabinet, and four fasteners/washers on the bottom. Refer to **Figure 18**.

1. Mark locations in the top and bottom angle-iron of the utility cabinet.
2. Drill pilot holes for fasteners.
3. When installing to the wall:
 - Concrete/Masonry - use 5/16" x 2-1/4" Tapcons.
 - Metal Studs - use 5/16" x 1-1/2" Self Drilling Screws.
 - Wooden Studs - use 5/16" x 3-1/2" Lag Bolts.
 - Drywall (only) - use 5/16" x 4" Long Toggle Bolts.

NOTE: Wall-mounted utility cabinets up to 48" long, must be secured to 2 studs minimum (top and bottom of the utility cabinet). Wall-mounted utility cabinets over 48" long, must be secured to 3 studs minimum (top and bottom of the utility cabinet).

Figure 18 - Wall-Mount Details



Duct and Plenum Protection

The TANK Fire Suppression extinguishing system for duct and plenum coverage can be provided by independent fire suppression tanks and piping or integrated with the fire suppression tanks and piping used for protection of the appliances. Max of 5 nozzles per TANK for duct and plenum coverage only. Each duct and plenum nozzle protection is 4 flow points.

Plenum Protection

The nozzle(s) (**page 12**), are used to protect plenum areas in both single bank and V-bank plenum configurations. The nozzle will protect up to a 4' wide x 10' long plenum section. For larger plenum areas, additional nozzles are added as required, with each nozzle protecting no more than a 4' wide by 10' long plenum section. Nozzles may be installed pointing in the same direction, and/or at opposite ends of the plenum, pointing toward each other. The nozzles must not be installed back-to-back when protecting plenum areas. When positioned at the end of the plenum, nozzles must be installed from 0 to 6" into plenum. If the riser is not centered on the plenum, the plenum nozzle is placed on the side of the plenum closest to the riser.

The nozzle locations for plenum protection are shown in **Figure 19** and **Figure 20**.

Figure 19 - Single Bank Filter Plenum





Figure 20 - Dual V-Bank Filter Plenum




Duct Protection

The nozzle(s) ([page 12](#)) is used for the protection of exhaust ductwork and can protect any duct cross-section type (e.g. round, square, or rectangular). A sufficient quantity of nozzles must be provided to ensure that no single nozzle coverage exceeds 75" in perimeter.

A single nozzle will protect a duct up to 75" perimeter (22" nominal diameter) and unlimited length. Two nozzles are required for protection of 75-150" perimeter and unlimited length. A minimum of 3 nozzles is required for protection of ducts exceeding 150" perimeter (36" nominal diameter) and unlimited length.

When using multiple nozzles (modular protection), the coverage area for each nozzle must not exceed 75" perimeter.

Figure 21 - Nozzle Duct Protection




Nozzles must be installed from 0" to 6" into the protected area of the duct. When more than one nozzle is required (modular protection), each nozzle must be located at the center of its protected module area. Additional nozzles are not required for changes in direction*. Duct obstructions and common ductwork must be protected in accordance with this manual, NFPA 17A and NFPA 96.

The nozzle location and aim for duct protection are shown in **Figure 22** and **Figure 23**.

*When a change in direction occurs less than 6" from the duct entrance, the nozzle must be aimed as shown in **Figure 22** and **Figure 23**.

Figure 22 - Single Nozzle Placement (0-75" Perimeter Duct)




1. Nozzle
2. Horizontal Duct Centerline (CL)
3. Aim Point
4. Vertical Duct Centerline (CL)
5. Duct Entrance

- A. Rectangular Duct Width
- B. Rectangular Duct Length

- Duct perimeter up to and including 75" (1270mm).
- To determine the perimeter: $2(A) + 2(B) = 75"$ (1905 mm).

Figure 23 - Dual Nozzle Placement (75-150" Perimeter Duct)



Ventilation Exhaust and Dampers

The TANK Fire Suppression extinguishing system can be used with the exhaust fan either on or off when the system is discharged. It is recommended that the exhaust fan remain on at the time of discharge to aid in the removal of smoke, gases, and other airborne materials from the hazard area in the event of a fire. If the Authority Having Jurisdiction (AHJ) requires that the damper closes in the event of a fire system discharge, the system designer shall provide for protection downstream of the damper in compliance with NFPA 96, local codes, and/or as approved by the AHJ.

Electrostatic Precipitators (ESP)

An Electrostatic Precipitator (ESP) is designed to remove smoke and other airborne contaminants from the air flowing through the exhaust ductwork as a means of pollution control. Exhaust ductwork using ESPs requires Overlapping Male nozzle(s) (p/n OL-M [previously 3070-3/8HH-10-SS]) upstream, before the ESP. Distribution piping to the nozzles must not interfere with the function of the ESP unit.

A Pollution Control Unit (PCU) and/or Electrostatic Precipitator (ESP) covered with this fire system can utilize up to 12 nozzles per tank.

Appliance Protection

The TANK Fire Suppression system utilizes both overlapping and dedicated nozzle appliance coverage, depending on the type of cooking appliance(s) requiring protection. The Hazard Zone consists of the cooking surface of each appliance underneath each hood. For dedicated and overlapping nozzle information, refer to **“Nozzles” on page 12**.

Overlapping appliance coverage allows a given area under the hood, defined as the hazard zone, to be protected by overlapping nozzles. Nozzles are evenly spaced at the same height and alignment (front-to-back) relative to the hazard zone.

Dedicated appliance protection utilizes a nozzle, or nozzles, for protection of an individual appliance.

Overlapping, dedicated appliance, plenum, and duct protection may be incorporated in a single pipe network on the TANK Fire Suppression extinguishing system, as long as the number of nozzles per tank does not exceed five. **Mixed flow points may be used in the system as long as they do not exceed maximum tank flow points.**


The following sections detail the different nozzle coverage and placement parameters for overlapping and dedicated nozzle appliance protection methodologies. Double row coverage is allowed for TANK.

Overlapping Appliance Protection

A single hazard zone utilizing overlapping coverage is 30" deep, by the total length of the hazard zone for the protected appliances. The cooking surface of all appliances protected by overlapping nozzles must be located within the defined hazard zone area. Cooking appliances eligible for overlapping protection are outlined in **Table 2 on page 25**. The lowest and highest cooking surface will determine the height of the fire suppression nozzles. All overlapping nozzles must be mounted at the same height in a single hazard zone.

For applications where overlapping protection cannot be used, such as an upright boiler, dedicated appliance protection must be used.

Figure 24 - Overlapping Protection Option



Appliance Coverage

Table 2 displays the maximum permitted hazard zone dimensions of each appliance that can be protected within a single overlapping zone. It is important to note that the hazard zone (area requiring protection) is different than the total appliance size. **Figure 24** illustrates the placement of nozzles for TANK Fire Suppression overlapping protection.

**Table 2 - Standard Overlapping Protection 5 nozzles per tank (20 flow points),
36" max nozzle spacing**

Hazard	Fuel Source	Maximum Depth of Hazard Zone	Maximum Length of Hazard Zone	Maximum Height of Fuel
Multi/Single Vat Fryer (with or without Drip-board) ^{(3) (7)}	Gas or Electric	30" deep	Unlimited	N/A
Split Vat Fryer (with or without Drip-board) ^{(3) (7)}	Gas or Electric	30" deep	Unlimited	N/A
Griddle	Gas or Electric	30" deep	Unlimited	N/A
Gas/Electric Radiant Charbroiler (with or without Ceramic/Lava Rock)	Gas or Electric	30" deep	Unlimited	N/A
Upright Broiler/Chain Broiler/Salamander ⁽⁸⁾	Gas or Electric	30" deep	Unlimited	N/A
Appliance without Shelf/Obstruction ⁽⁸⁾	Gas or Electric	30" deep	Unlimited	N/A
Range without Shelf/Obstruction ⁽⁸⁾	Gas or Electric	30" deep	Unlimited	N/A
Wok	Gas or Electric	11-24" diameter	11-24" diameter	6-3/4" deep

Notes:

1. All dimensions shown are based on overlapping protection.
2. All dimensions and areas shown reference the hazard zone of the appliance, which is typically smaller than the outside dimensions of the appliance itself.
3. For multi-vat fryers, no single fryer module (vat & drip board) can exceed the above limitations. Nozzle height(s) for fryers should be taken from the fryer's maximum level indicator. When no maximum level indicator is present, nozzle height(s) should be taken from the top of the vat to no more than 3" below.
4. All appliance hazard surfaces must be located within the hazard zone.
5. Smaller appliances can be positioned anywhere in the zone (e.g., moved left, right, forward, or backward, provided the cooking hazard does not extend beyond the perimeter of the zone).
6. When the depth of the appliance exceeds maximum cooking hazard dimensions, a second row of nozzle coverage should be added.
7. Deep Fat and Industrial Fryers over 14" wide, a vat area of 196 in², or oil capacity of 50 lbs will need to refer to **Table 4 on page 26** for coverage information. Max oil capacity: 192.5 lbs.
8. Any appliance that may be obstructed (e.g. shelf, salamander, etc.), requires dedicated coverage. Refer to **"Upright Broiler/Salamander Protection" on page 30**, **"Appliance with Shelf" on page 31**, and **"Over-head Obstruction/Salamander Protection" on page 34** for coverage information.
9. For information on Tilt Skillets/Braising Pan coverage, refer to **Table 3 on page 26**.
10. Appliances not covered in **Table 2** through **Table 6**, refer to **"Other Appliance Coverage" on page 27**.

Table 3 - Overlapping Protection 5 nozzles per tank (20 flow points), 30” max nozzle spacing

Hazard	Fuel Source	Maximum Depth of Hazard Zones	Maximum Length of Hazard Zones	Maximum Height of Fuel
Tilt Skillet/Braising Pan	Gas or Electric	30” deep	Unlimited	N/A

Tilt skillets and braising pans should be placed at the back of the hazard zone. Tilt skillet coverage must not interfere with the edge of the nozzle discharge pattern.

Nozzles may need to be moved forward and angled back to avoid the tilt skillet lid. Refer to **“Overhead Obstruction/Salamander Protection” on page 34** for nozzle coverage.

Table 4 - Overlapping Protection 4 nozzles per tank (20 flow points), 30” max nozzle spacing

Hazard	Fuel Source	Maximum Depth of Hazard Zones	Maximum Length of Hazard Zones	Maximum Height of Fuel
Deep Fat/Industrial Fryers (with or w/o Drip-board)	Gas or Electric	34” deep	Unlimited	N/A
Pressure Fryers*	Gas or Electric	34” deep	Unlimited	N/A
Wok	Gas or Electric	Greater than 24”, up to 30” diameter	30 inch diameter	9-1/2” deep

Deep Fat, Industrial and Pressure Fryers Max oil capacity: 192.5 lbs.

Nozzle height(s) for fryers should be taken from the fryer’s maximum level indicator. When no maximum level indicator is present, nozzle height(s) should be taken from the top of the vat to no more than 3” below.

For more information on Tandoor oven coverage, refer to **“Other Appliance Coverage” on page 27**.

*Henny Penny fryer models 690, 691, 692, PXE-100, and similar rail type lidded pressure fryers are allowed with standard 30” max nozzle spacing as long as the nozzle flow pattern is not obstructed by the lid while in the fully open position. A nozzle is required on both sides of the lid. Refer to Hinged Lid/Rail Type Pressure Fryers on **page 27** for more information.

Table 5 - Appliances using 3 nozzles per tank, 24” max nozzle spacing

Hazard	Fuel Source	Maximum Depth of Hazard Zones	Maximum Length of Hazard Zones	Maximum Height of Fuel
Natural Charcoal Broiler	Charcoal	30” deep	Unlimited	4”
Solid Fuel Charbroiler	Mesquite or Hardwood	30” deep	Unlimited	6”

Table 6 - Appliance with Shelf 4 nozzles per tank (20 flow points), 36” max nozzle spacing

Hazard	Fuel Source	Maximum Depth of Hazard Zones	Maximum Length of Hazard Zones	Maximum Height of Fuel
Less than 12” Back Shelf	Gas or Electric	30” deep	Unlimited	N/A
12” Back Shelf	Gas or Electric	30” deep	Unlimited	N/A

Shelves/protrusions from appliances measuring 6” or less are not considered obstructions. Standard overlapping coverage applies. Refer to **Table 2 on page 25**.

Shelves/obstructions greater than 6” and up to 12” require 4 nozzles per tank, 36” max nozzle spacing.

Shelves exactly at 12” depth require 35” distance from nozzle tip to cooking surface. Shelves less than 12” may use nozzle distance from cooking surface of 35” to 50”, every effort should be taken to minimize nozzle spray pattern obstruction with the shelf. Refer to **“Appliance with Shelf” on page 31** for more information.

Other Appliance Coverage

Appliances that are not covered in the UL300 Standard should use the following manufacturer's recommendations.

- **Enclosed electric rotisserie ovens** - Appliance protection is generally not needed unless required by the Authority Having Jurisdiction (AHJ).
- **Enclosed gas rotisserie ovens** - Standard overlapping protection with 36" max spacing is recommended to direct suppressing agent onto the top of the appliance and into the flue. Refer to **Table 2 on page 25**.
- **Open front gas/electric rotisseries** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended. Follow Upright Broiler information located on **page 25**.
- **Open top gas/electric rotisseries** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended. Follow Radiant Broiler information located on **page 25**.
- **Clamshell Griddle** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended. Follow Griddle information located on **page 25**.
 - Nozzles should be positioned to avoid obstruction of nozzle flow.
 - If the upper platen obstructs the nozzle flow/overlapping coverage, either all nozzles within the same zone will be moved forward (in front of the upper platen) and angled back to the cooking surface; Or a separate overlapping coverage zone will be used for the equipment and the nozzles in that zone will be moved forward (in front of the upper platen) and angled back to the cooking surface.
 - Nozzle position should follow the 35-50" nozzle to cooking surface requirement of other overlapping coverages.
- **Vertical/Gyro Broilers** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended for vertical/gyro broilers. Nozzles should be positioned to avoid obstruction of nozzle flow. Follow Gas Electric Radiant Charbroiler information located on **page 25**.
 - Nozzle position should follow the 35-50" nozzle to cooking surface, the Gyro Broiler cooking surface should be the grease collection drip pan.
- **Round Fry Vats** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended for vats up to 14" in diameter. Follow Multi Vat/Single Vat/Split Vat Fryer information located on **page 25**.
 - Larger diameters up to 34" should be protected using 30" overlapping coverage (5 FP per nozzle). Follow Deep Fat/Industrial Fryers (with or w/o Drip-board) information in **Table 4 on page 26**.
- **Hinged Lid/Rail Type Pressure Fryers** - Overlapping coverage, appropriate to the size of the fry vat, can be used if the lid opens automatically once it is unlatched from the normal cooking position, is fully out of the way, and does not obstruct the nozzle flow.
 - Standard 36" overlapping coverage (4 FP per nozzle) is recommended for vats up to 14" wide. Follow Multi Vat/Single Vat information located on **page 25**. Deep Fat and Industrial Fryers over 14" wide, a vat area over 196 in², or oil capacity over 50 lbs will need to refer to **Table 4 on page 26** for coverage information. Max oil capacity: 192.5 lbs.
- **Smoker with Eyebrow Hood** - Recommended protection for eyebrow hoods is based on solid fuel charbroiler coverage as outlined in **Table 5 on page 26**, which includes overlapping appliance nozzles spaced no more than 24" apart and no more than 12" from the edge of the coverage zone with each nozzle counting as 6 FP each.
 - The coverage zone shall be defined as a 12" deep area spanning the oven horizontal opening. The center of the coverage zone shall be defined as 6" in front of the opening.
 - Single row coverage shall suffice.
- **Tandoor Ovens** - Standard 36" overlapping coverage (4 FP per nozzle) is recommended for Gas Radiant or Electric Tandoor Ovens having an opening of 14" diameter or smaller. Refer to Gas/Electric Radiant Charbroiler (with or without Ceramic) information on **page 25**. Gas Radiant or Electric Tandoor Ovens having an opening over 14" diameter must use (5 FP per nozzle) 30" overlapping coverage. Refer to **Table 4 on page 26**.
 - **NOTE: All wet chemical fire systems risk cracking clay tandoor ovens in the event of a fire system activation.**

Overlapping Protection

Standard overlapping protection is 5 nozzles (20 flow points) at 36" max spacing, refer to **Table 2 on page 25**. All overlapping nozzles must be spaced no more than 12" from each end of the appliance, and located at the centerline of the 30" hazard zone (front to back), at the same height, and aimed straight down. The nozzle height must be 35" to 50" above the appliance cooking surface, except for woks, where the height is measured 3 inches below the top rim of the wok. The nozzles must be positioned along the total hazard zone length to allow protection of each appliance in the hazard zone.

Exceptions to standard overlapping protection: Refer to **Table 3 through Table 6 on page 26** for more information.

- Large/Industrial fryers over 14" wide, 4 nozzles at 30" max nozzle spacing per tank.
- Woks larger than 24 inch diameter, 4 nozzles at 30" max spacing per tank.
- Appliance with shelves, 4 nozzles at 36" max spacing per tank.
- Solid Fuel Appliances, 3 nozzles at 24" max spacing per tank.

Refer to **Table 4 through Table 6 on page 26** for more information.

Overlapping Coverage - Group Protection

Overlapping protection provides coverage for a continuous hazard zone, with all nozzles at consistent position (i.e., zone centerline), spacing, and height.

When there is an area within a hazard zone for which continuous overlapping coverage is not applicable, the overlapping protection zone may be ended, and a new zone started for the new group of appliances. Examples where continuous protection may be interrupted include (but not limited to) a counter, storage or prep area, appliance not requiring protection (e.g., enclosed electric oven) or an appliance requiring dedicated appliance coverage.

The examples on **page 29** provide details of group overlapping protection for interrupted zones. This section illustrates the methodology for defining when a new hazard zone is required, as described above. For appliance specific overlapping coverage parameters (e.g., nozzle spacing and height requirements), refer to **page 30 through page 36**.


NOTE: Overlapping nozzle spacing and height requirements are based on the appliances protected for each individual zone. Nozzles must always be located at the start and end of each zone, no more than 12" from the end of the hazard zone (edge of 1st/last cooking appliance surface). Refer to "Overlapping Appliance Protection" on page 24. Zones cannot overlap.

NOTE: All hazard surfaces in a zone must be within 35"-50" of the nozzles in that zone.

Group Protection Example 1 - Appliance line separated by unprotected space.

End nozzles must be located 12" or less (horizontally) from the end of the hazard zone. Standard overlapping nozzles must be spaced no further than the maximum allowed interval 36" on center. Refer to "**Appliance Coverage**" on page 25 for more details on coverage information.


Figure 25 - Example 1



Example 2 - Appliance lines with overlapping nozzles at different heights

Figure 26 - Example 2

- A. Zone 1 Overlapping Nozzle Spacing
B. Zone 1 Overlapping Nozzle Height
C. Zone 2 Overlapping Nozzle Spacing
D. Zone 2 Overlapping Nozzle Height




Upright Broiler/Salamander Protection

Upright broilers, chain broilers, and cheesemelters have specific coverage requirements. Unlike appliances with an exposed flat cooking surface, these appliances have an internal cooking surface and only have a small opening in the face or end of the appliance.

To cover internal hazards posed by these appliances, an Overlapping Female (OL-F) nozzle (previously 3070-3/8H-10-SS) must be placed at the opening and aimed at the opposite rear corner of the appliance. This nozzle must be branched off one of the nozzle drops and piped to the appliance opening. **No more than 2 nozzles per drop.** The drawing below illustrates how this should be accomplished. Should the cooking surface of the appliance exceed 1,050 in², an additional nozzle will be required on the opposite of the appliance for added fire protection. Refer to **Figure 27** for details.

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing and copper Pro-Press fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
4. Install union in pipe leading to nozzle to allow for appliance removal and cleaning.
5. Nozzle heights above cooking surface (DIM A).
6. In addition to Standard Overlapping Protection, additional nozzles may be utilized for supplemental appliance specific protection. No more than two (2) nozzles may be used on a single drop.
7. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.

Figure 27 - Broiler/Salamander Protection




Appliance with Shelf

An Overlapping Female (OL-F) Nozzle (previously 3070-3/8H-10-SS) is used for Appliance Top Cooking equipment protection. This type of cooking equipment is available with multiple burner assemblies. Some appliances are equipped with shelving behind the appliance for additional storage. **Figure 28** illustrates the shelf cannot overhang the appliance more than 12" from the back of the cooking surface.

All dimensions fixed unless otherwise noted (e.g., min/max).

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing/fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
4. Nozzle heights above cooking surface (DIM A).
5. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.
6. Shelves or protrusions from appliances measuring 6" or less are not considered obstructions. Standard overlapping coverage applies. Refer to **"Appliance Coverage"** on page 25.

Figure 28 - Appliance with Shelf



1. Overlapping Nozzle (OL-F)


2. Shelf - 12" maximum distance from the rear edge of the cooking hazard to the front edge of the shelf.

Wok Protection

An Overlapping Female (OL-F) Nozzle (previously 3070-3/8H-10-SS) is used for Wok protection. The nozzle must be located within 12" from the left or right of the Wok and 15" from the front or back of the Wok. The Wok diameter range for protection is 11" to 24" diameter. For woks that exceed the 24" diameter, refer to "**Large Wok Protection**" on page 33.

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing/fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Nozzle heights above cooking surface (DIM A).
4. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
5. Install drops at 36" maximum spacing.
6. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.

Figure 29 - Wok Diameter Protection (up to 24")




Large Wok Protection

An Overlapping Female (OL-F) Nozzle (previously 3070-3/8H-10-SS) is used for Wok protection. The nozzle must be located within 12" from the left or right of the Wok and 15" from the front or back of the Wok. The Wok diameter range for protection is 30" diameter. 4 nozzles per tank, 30" max nozzle spacing.

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing/fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
4. Nozzle heights above cooking surface (DIM A).
5. Install drops at 30" maximum spacing.
6. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.

Figure 30 - Wok Diameter Protection (up to 30")



Overhead Obstruction/Salamander Protection

Salamanders/Cheesemelters have specific coverage requirements, unlike appliances with an exposed flat cooking surface, these appliances have an internal cooking surface and only have a small opening in the face or end of the appliance. **Dedicated nozzles are not required when the overhead obstruction is not an appliance.**


To cover internal hazards posed by these appliances, an Overlapping Female (OL-F) nozzle (previously 3070-3/8H-10-SS), is placed at the opening and aimed at the opposite rear corner of the appliance. The nozzle may be branched off one of the nozzle drops with a tee or have a dedicated nozzle drop and piped to the appliance opening. No more than two nozzles can be utilized for a single drop. Should the cooking surface of the appliance exceed 1050 in², an additional nozzle will be required on the opposite side of the appliance for added fire protection, refer to **Figure 31**.

Additional nozzles may be piped from nozzle drops nearest the appliance, or have a dedicated nozzle drop to cover the hazard underneath the obstruction/salamander. The nozzles are aimed at the centerline of the cooking surface, a minimum of 35"-50" away (DIM A). **Overlapping coverage is required for the appliance below the obstruction, nozzles may need to be moved forward and angled back to avoid the obstruction.**

All dimensions fixed unless otherwise noted (e.g., min/max).

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing/fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
4. Install union in pipe leading to nozzle to allow for appliance removal and cleaning.
5. In addition to Standard Overlapping Protection, additional nozzles may be utilized for supplemental appliance specific protection. No more than two (2) nozzles may be used on a single drop.
6. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.
7. Shelf/obstruction that extends more than 10-12" from the rear edge of the cooking hazard to the front edge of shelf/obstruction.
8. The spacing between nozzles will be either 36" or 30" maximum, based on the overlapping protection required for the appliance hazard below the obstruction.

Figure 31 - Appliance with Upright Obstruction



1. Overlapping Nozzle (OL-F)
2. Broiler/Salamander Protection Nozzle (OL-F)
3. Union in Pipe
4. Internal Cooking Surface

Pizza Ovens

Pizza ovens have specific coverage requirements, unlike appliances with an exposed flat cooking surface, these appliances have an internal cooking area and only have a small opening in the face or end of the appliance. When installing the appliance, make sure the nozzle does not obstruct cooking operations.

To cover the internal hazard posed by these appliances, an Overlapping Female (OL-F) nozzle (previously 3070-3/8H-10-SS) must be placed at the opening and aimed at the opposite rear corner of the appliance. No more than two nozzles can be utilized for a single drop. Refer to **Figure 32** for single stack ovens.

Figure 33 and **Figure 34** on page 36 show dual and three stack oven installation examples. Should the cooking area of the appliance exceed 1200 in², an additional nozzle will be required on the opposite side of the appliance for added fire protection. Each nozzle can cover 1200 in².

Hard piping is typically used to cover conveyor style pizza ovens, but a agent distribution hose is available for order (part number DISFLEXHOSE). This hose and restraining cable kit may be used when covering a conveyor pizza oven. The flexible hose allows for mounting directly to the pizza oven. When the hose is positioned such that the nozzle is pointed to the opposite corner of the pizza oven, it will provide similar coverage as a hard piped fire system drop.

All dimensions fixed unless otherwise noted (e.g., min/max).

1. Pipe and fittings above the hood will be 1/2" copper pipe/Pro-Press, Grade L copper tubing/fittings.
2. Pipe and fittings inside the hood capture volume will be 3/8" NPT stainless steel or chrome-plated black iron. No sleeving permitted.
3. Appliance coverage piping that is field piped - unions, elbows, and nozzles factory provided.
4. No more than two (2) nozzles may be used on a single drop.
5. Appliance drop fittings may be sealed with pipe dope or Teflon tape. Drops must be installed with an internal pipe wrench or other no-marring pipe tool.

Figure 32 - Single Stack Pizza Oven




Figure 33 - Double Stack Pizza Oven





Figure 34 - Triple Stack Pizza Oven



Agent Distribution Piping

The agent distribution piping shall be 3/8" NPT Schedule 40 black iron, 3/8" NPT Schedule 40 stainless steel, or 1/2" copper pipe (Grade L) and Pro-Press fittings. Fittings shall be minimum class 150. Nozzle drops cannot be sleeved in steel but can be made from polished stainless steel, or polished chrome-plated black iron.

Galvanized pipe or fittings must not be used. Pipe thread or compound should be used to help seal fittings.

Distribution piping can be run in single cylinder or dual cylinder manifold configurations. Refer to **page 39** for single cylinder and dual cylinder configuration details.

The distribution network consists of a supply line and all applicable branches depending on the protected hazards. Branch lines include the plenum branch, duct branch, overlapping nozzle appliance branch, and dedicated nozzle appliance branch.

The supply line is defined as the run of all pipe and fittings from the tank outlet to the last branch line, including fittings at the start of all branch lines. All branch lines start at the outlet of the applicable supply line fitting and do not include the supply tee.

A plenum branch is defined as the run of all pipe and fittings from the supply line tee outlet to the plenum nozzle(s).

A duct branch is defined as the run of all pipe and fittings from the supply line tee outlet to the duct nozzle(s). Duct branch lines on risers greater than 75 inch perimeter can have a "tee" installed. Two separate duct branch lines are not required.

An overlapping nozzle appliance branch is defined as the run of all pipe and fittings from the supply line tee outlet to the nozzle.


A dedicated nozzle appliance branch is defined as the run of all pipe and fittings from the supply line tee outlet to the nozzle.

Refer to **page 38** and **page 39** for Supply Line, Plenum Branch, Duct Branch, Overlapping Nozzle Appliance, and Dedicated Nozzle Appliance information.


Refer to “Cylinder Nozzle and Piping Parameters” on page 39 for supply line and branch piping limitations.

Figure 35 - Distribution Piping

Hood Mounted Utility Cabinet Distribution Piping Example



Wall Mounted Utility Cabinet Distribution Piping Example



Cylinder Nozzle and Piping Parameters

A single cylinder supports up to 5 nozzles, 20 flow points. Max supply line up to 42 feet to the first overlapping nozzle.

A dual cylinder system supports up to 40 flow points and 10 nozzles. Dual cylinder systems can be piped in series or parallel. Max supply line up to 42 feet to the first overlapping nozzle.

Table 7 - Agent Distribution Piping Limitations

Pipe Section	Max Pipe Length (ft)
Max Supply Line to First Overlapping Nozzle	42
Overlapping Nozzle Appliance Branch	10
Dedicated Nozzle Appliance Branch	10

Notes:

1. One (1) tee allowed per appliance drop.
2. No more than two nozzles can be utilized for a single appliance drop.
3. Additional elbows are permitted on branch lines and horizontal supply piping, provided linear pipe length is reduced by corresponding equivalent length (1.3 ft per 90° elbow, 0.6 ft per 45° elbow).
For example: a 3/8" steel elbow has an equivalent length of 1.3 ft. An appliance branch may use 4 elbows, provided the total linear pipe is reduced by 1.3 ft (e.g., from 5 ft to 3.7 ft). Additional pipe cannot be added in lieu of fittings, as pipe volume limits could be exceeded.
4. Maximum 6 ft vertical rise of supply line above cylinder outlet.
5. Minimum 7 ft. of supply line to first overlapping nozzle.
6. If hoods are piped to the same tank, the sum of piping between hoods plus distance to first overlapping nozzle should NOT exceed 42 feet.

Nozzle Installation

Distribution piping and nozzles are factory-installed. Verify that the nozzles and distribution network are installed in accordance with the design and installation parameters for all protected hazards, as set forth in this manual.

NOTE: The TANK Fire Suppression extinguishing system design must be reviewed if any hazard changes have been made, including (but not limited to): appliance type, appliance sizes, appliance location, factory pre-piping or nozzles, plenum size or configuration, and duct size or configuration.

1. Ensure nozzles are securely installed. DO NOT OVERTIGHTEN.

NOTE: Do not over-tighten or nozzles may be damaged.

2. Ensure all nozzle types, placement, and aim are in accordance with the limitations in this manual. Nozzles can be used to achieve proper aim on dedicated appliance protection nozzles only.
3. Refer to “**Nozzles**” on page 12 for details on nozzle(s).

Gas Shut-Off Valves

The electric gas valve is held open in the energized state, and closes when de-energized via the output relay of the control panel. A listed manual reset relay is required to ensure manual reset prior to fuel being restored in accordance to NFPA17A.

Gas valves (**Figure 36**) are designed to shut off the flow of gas to the kitchen appliances in the event of fire system activation. Electric gas shutoff valves must be installed with an upstream strainer to prevent debris from prohibiting gas valve function. New pipe, properly reamed and cleaned of metal burrs, should be used. Proper care is needed to ensure that the gas flow is in the same direction as indicated on the gas valve and strainer. Do not over-tighten pipe connections. Apply pipe dope to the male threads only.

If necessary, install a drip leg in the gas line in accordance with the Authority Having Jurisdiction (AHJ).

Proper clearance must be provided in order to service the strainers. A minimum of 4" clearance distance must be provided at the base of the strainer.

Refer to “**Gas Valve Orientation**” on page 41 for installation views.

Figure 36 - Electric Gas Valve




Table 8 - Gas Valve Details

120V AC Gas Valve	24V DC Gas Valve	Size	DIM "A"	DIM "B"	DIM "C"	DIM "D"	DIM "F"	DIM "G"
8214235	8214G236-24VDC	3/4"	6-15/16"	5-15/16"	4"	4-1/2"	11-15/16"	9-7/8"
8214250	8214G251-24VDC	1"	6-15/16"	5-15/16"	4-7/8"	5-3/16"	12-13/16"	10-11/16"
8214265	8214G266-24VDC	1-1/4"	7-5/8"	6-3/8"	5-1/8"	5-15/16"	13-1/2"	12-1/16"
8214275	8214G276-24VDC	1-1/2"	7-5/8"	6-3/8"	5-3/4"	6-3/16"	14-1/8"	12-5/16"
8214280	8214G281-24VDC	2"	7-5/8"	6-3/8"	7-1/4"	7-13/16"	15-5/8"	13-15/16"
8214290	-	2-1/2"	10-5/16"	8-1/16"	8-7/8"	9-7/8"	18-15/16"	18-5/8"
8214240	-	3"	10-5/16"	8-1/16"	10"	10-15/16"	20-1/16"	19-11/16"


A gas strainer is supplied with the unit and recommended to be installed.

Gas Valve Orientation

For gas valve operation and details, refer to “**Gas Shut-Off Valves**” on page 40. Verify the size of the gas valve. This will determine the mounting and installation for proper operation of the gas valve and solenoid.

For **3/4” - 2” 120V AC** gas valves, the solenoid can be mounted in any position at or above horizontal. The gas pipe may be vertical or horizontal. Refer to **Figure 37**.

Figure 37 - Solenoid At or Above Horizontal/Pipe Vertical or Horizontal



For **2-1/2” - 3” 120V AC** gas valves, the solenoid must be mounted with the solenoid vertical and upright. The gas pipe must be horizontal. Refer to **Figure 38**.

All **24V DC** gas valves must be mounted with the solenoid vertical and upright. The gas pipe must be horizontal. Refer to **Figure 38**.

Figure 38 - Solenoid Vertical and Upright/Pipe Horizontal





Figure 39 - Firestat Installation Details



* Application specific, refer to **page 58** for details.

Firestat Components

1. Hood Riser Firestat
 - Fenwal Part Number - 12-F28021-32144-OT-360 - Normally Open, Close on Rise @ 360°F
 - Fenwal Part Number - 12-H28021-12144-OT-600 - Normally Open, Close on Rise @ 600°F
2. Wiring - 2 black wires/2 white wires.
3. Seal threads with Teflon Tape before installation
4. 1/2" NPT Quick Seal (Adapter Body) - Part Number Kit 32-00002
5. 1/2" NPT Quik Seal (Gasket) - Part Number Kit 32-00002
6. External Surface of hood/duct.
7. 1 1/8" - 1 1/4" diameter hole.
8. 1/2" NPT Quik Seal (Lock Washer) - Part Number Kit 32-00002
9. 1/2" NPT Quik Seal (Nut) - Part Number Kit 32-00002
10. 1/2" flex conduit connector - Part Number A009088
11. Flex metallic conduit to ECP junction box (closest to the hood) - Part Number A0005719
12. Duct Protection Firestat
 - Fenwal Part Number 12-F28021-005360 - Normally Open, Close on Rise @ 360°F
 - Fenwal Part Number 12-H28021-005-OT-600 - Normally Open, Close on Rise @ 600°F
13. Extension Ring - Part Number 59361-1/2
14. Extension Ring Cover - Part Number 100-BW


Hood Riser Sensor Replacement

The following instructions are for replacing a hood duct stat or fire stat located in the riser.

NOTE: Make sure the fire system is deactivated and all controls are powered down before servicing the unit. Service should only be performed by trained personnel.

1. Locate faulty sensor in hood riser. Remove the hood filters to access from the hood plenum.
2. Determine the location of the sensor's lead ends. This will either be on the top of the hood, in the junction box which has conduit routed to the riser, or in the electrical control package that is mounted on the hood (if it is a stand-alone hood).
3. Access the sensor's lead ends and remove Wago connectors. Attach a fish tape (or pulling rope) to the lead ends.
4. Unscrew the sensor from the quick seal in hood plenum. Pull leads completely out, pulling the fish tape until exposed.
5. Attach replacement sensor to fish tape and pull back through conduit until lead ends are back in the original location.
6. Replace Wago connectors on the new sensor's lead ends.
7. Twist new sensor counterclockwise, 2-1/2 turns to pre-tension wires. Thread sensor in riser quick seal (using Teflon tape on threads).
8. Replace hood filters.
9. Power up the system to test functionality.

Figure 40 - Sensor Replacement



Fire Protection Manual Actuation Device

The push/pull station (**Figure 41**) is a remote manual actuation device to activate the fire system. This remote manual actuation device (push/pull station) contains one set of normally open contacts and mounts to any standard single gang junction box. When the front button is pressed, the electrical connection to the fire system is completed, thus activating the fire system.

The remote manual actuation device (push/pull station) should be mounted at a point of egress and positioned at a height determined by the Authority Having Jurisdiction (AHJ). This position is usually 10 to 20 feet from hood and 42 to 48 inches above the floor. Multiple remote manual actuation devices (push/pull stations) are acceptable to use in the fire system and are wired in parallel per the electrical schematic. The remote manual actuation device (push/pull station) is reset by twisting the push-button clockwise until the internal latch is released.

The clear protective cover must be installed to protect the device from accidental activations. This cover is provided as part of the manual actuation device. Refer to **Table 9** for device part numbers and replacement parts.

NOTE: When connecting the wires to the push/pull station, do not twist the wire ends together. Insert each wire on the opposite side of the screw.

Figure 41 - Manual Activation Device




Table 9 - Activation Device Part Numbers


Part Description	Part Number
Push-Button with Clear Cover	SS2031ZA-EN
Push-Button with Clear Cover and Horn	SS2041ZA-EN
Red Junction Box with Deep Back for Surface Mount	STI-KIT71101AR
Normally Open Contact	STI-10196
Contact Housing Assembly	SF-10197H

Trouble Input Wiring

Trouble contacts and supervision switches from each device may be connected to the optional trouble input of the building fire alarm panel to indicate a trouble condition.

Figure 42 - Optional Wiring Connection for Trouble Contact

1. Building Fire Alarm
2. CORE Control Panel Trouble Contact
3. End of Line Device
4. Building Fire Alarm - Trouble Input Wiring



Fire Protection System Printed Circuit Board

The fire protection system printed circuit board (PCBCORE) is a microprocessor-based controller that provides all the necessary monitoring, timing, and supervision functions required for the reliable operation of the fire system.

Under normal conditions, the “Fire System Status” light is on. This indicates the system is armed and active. If a fault is detected anywhere in the system, an audible alarm will periodically sound, and the “Fire System Status” light will flash a fault code to indicate the fault that was detected. The HMI, located on the hood or Electrical Control Package (ECP), will display the fault text to explain where the issue is located in the system. Refer to **“CORE Board Faults” on page 60**.

NOTE: CORE Boards with software version 1.68 and prior will use one brief flash every 3-seconds to indicate there are no faults in the fire system.


When viewing the CORE Board, if a series of flashes followed by a pause exists, there is a fault in the system. Count the number of flashes between the pauses and refer to **“CORE Board Faults” on page 60**. Any fault is extremely important and must be corrected and rectified immediately to ensure proper operation of the fire system.

The optional connections for building fire panels are located at AL1 and AL2 as dry contacts.

For remote mounted Ansul Automans, use terminals AU1 and AU2. This will provide a dry contact connection point to provide power for activating the Ansul Automan.





NOTE: When a CORE board is connected to an ECPM03 board, if a fire condition happens, the “Last Fire Info” will be stored on the ECPM03 screen. “Last Fire Info” will be available on CASLINK as well.






Figure 43 - Printed Circuit Board



Connector Descriptions

Note: Some connections may not be used dependent on system configurations.

Connector J1 contains battery pack connections for battery charging and monitoring.	
Pin 1 – Battery Positive	Pin 2 – Battery Negative
Connector J2 contains Supervised Sensor Loop connections	
Pin 1 – Start Positive Loop Pin 2 – Start Negative Loop	Pin 3 – Finish Negative Loop Pin 4 – Finish Positive Loop
Connector J3 contains Power Supply and Device connections	
Pin 1 and Pin 2 – Positive Input, Power Supply Pin 3 and Pin 4 – Negative Input, Power Supply Pin 5 – Positive Output, Gas Valve Solenoid Pin 6 – Positive Output, Surfactant Pump Pin 7 – Positive Output, Release Valve Solenoid Pin 8 and Pin 9 – 24V DC Input, Shutoff Valve Supervision	Pin 10 – N/A Pin 11 – Drive Output, Fire Relay Pin 12 – Drive Output, 100% Relay Pin 13 – Drive Output, Trouble Relay Pin 14 – Drive Output, Wash Relay Pin 15 – Drive Output, Spare Relay Pin 16 – Drive Output, Auto-Man Relay
Connector J4 contains Power Supply and Device connections	
Pin 1 – Positive Input, Power Supply Pin 2 – Output, Panel Mounted Audible Alarm Pin 3 – Output, Panel Mounted LED Fire/Fault Indicator Pin 4 – N/A Pin 5 – Drive Output, Cooking Equipment Disable Relay Pin 6 – Negative Input, Power Supply Pin 7 – N/A	Pin 8 – Input, Pump Prime/Reset Push Button Pin 9 – Input, Gas Cartridge/Pressure Switch Pin 10 – Input, Fan Switch Pin 11 – Input, Gas Valve Reset Push Button Pin 12 – Input, Door/Tamper Switch Pin 13 – Input, Test Mode Pin 14 – Modbus Network, Common Signal (C) Pin 15 – Modbus Network, Negative Signal (A) Pin 16 – Modbus Network, Positive Signal (B)

Connector J5 and J6 is for RJ-45 connections	
These two connections are for the Modbus Network. This network may be used by non-fire system related equipment to monitor operating conditions of the electrical (PCBCORE) board.	
Connector J7 Interlock Network connections	
Pin 1 – Interlock Network, Common Signal (C) Pin 2 – Interlock Network, Negative Signal (A)	Pin 3 – Interlock Network, Positive Signal (B)
Connector J8 Interlock Network connections	
Factory Use Only	
Connector J9 is for Building Fire Alarm connections. A set of optional normally open dry contacts are available for signaling a building fire alarm panel if a fire condition is present.	
Pin 1 – Dry Contact Closure	Pin 2 – Dry Contact Closure
Connector J10 contains Supervised Sensor Loop connections	
Pin 1 – Start Positive Loop Pin 2 – Start Negative Loop	Pin 3 – Finish Negative Loop Pin 4 – Finish Positive Loop

Electrical

WARNING!

Disconnect power before installing or servicing control. High voltage electrical input is needed for this equipment. A qualified electrician should perform this work.

Before connecting power to the control package, read and understand the entire section of this document. As-built wiring diagrams are furnished with each control package from the factory and are either attached to the door of the unit or provided with the paperwork packet.

Electrical wiring and connections must be made in accordance with local ordinances and the National Electric Code, ANSI/NFPA70. Verify the voltage and phase of the power supply, and the wire amperage capacity is in accordance with the unit's nameplate.

ATTENTION: LOW-VOLTAGE DC OR SIGNALING WIRE SHOULD BE ROUTED IN SEPARATE CONDUIT FROM ALL AC VOLTAGE SOURCES.

1. Always **disconnect power** before working on or near this equipment. Lock and tag the disconnect switch or breaker to prevent accidental power-up.
2. **There are multiple electrical connections** required for this control. **120V AC** should be wired to terminals **H1** and **N1**. If the hood is equipped with a separate light circuit, **120V AC** should power this circuit per the as-built schematic. **H1** and **N1** should not be connected to a shunt trip breaker.
3. Verify that the power source is compatible with the requirements of your equipment. The system wiring schematic identifies the **proper phase and voltage** of the equipment.
4. Before connecting the control package to a power source, verify power source wiring is de-energized.
5. Secure the power cable to prevent contact with sharp objects.
6. Do not kink power cable and never allow the cable to come in contact with oil, grease, hot surfaces, or chemicals. Solenoid cables **must not** come in contact with hood surfaces.
7. **The supervised loop must be run through metallic conduit.** Do not run wiring with high voltage wires. Verify all supervised loop wires are free from damage/stress. All supervised loop wires must be terminated in terminal blocks, junction boxes, and push-stations.
8. If the system contains additional firestats, they must be wired into the supervised loop.
9. If the control package is a **wall-mount system**, a duct mounted temperature sensor will need to be wired. The temperature sensor must be wired to terminal blocks, as indicated on the wiring schematic.
10. If the control package is a **wall-mount system**, the hood lights wiring will need to be wired to terminals "B" and "W." Verify connections on wiring schematic.
11. Before powering up the system, make sure that the interior of the control package is free of loose debris or shipping materials.
12. The battery must be plugged in at connector J1 on the electrical board (PCBCORE) after wiring is complete.
13. All gas appliances under the hood must shut down in the event of an AC power loss. All electric appliances will shut down on building power loss.
14. If any original internal wire supplied with the system must be replaced, use type THHN wire or equivalent.
15. All field-supplied wire for the optional fire system release solenoid or firestat must be high temp wire rated for **842°F** minimum (#441601C6.FE9 White and #441601C6.FE0 Black) for on hood connections.
16. Use Belden #6320UL, 18 Gauge, plenum-rated wire or similar, for the optional fire system release solenoid or supervised loop that does not come in contact with the hood.
17. Use Belden #88760 or similar for the fire system interlock network and CAT-5 for Modbus communications.
18. All exterior wiring connections to the PCU must be run inside liquid tight conduit. This includes the supervised loop and airflow switch wiring.

IMPORTANT!: The battery backup for the fire protection system produces output power even when main power is disconnected from system. When performing major electrical service to the control, the battery backup must be disconnected then reconnected before commissioning.

Wire Ampacity Rating

The load current rating and the over-current protection for conductor types shall not exceed 15 amperes for 14 AWG, 20 amperes for 12 AWG, and 30 amperes for 10 AWG aluminum and copper-clad aluminum after any correction factors for ambient temperature and number of conductors have been applied. Refer to **Table 10**.

Table 10 - Copper Wire Ampacity @ 75°C

Wire Size AWG	Maximum Amps
14	15
12	20
10	30
8	50
6	65
4	85

Distance Limitations

Wiring connections to remote fire protection system(s) must use shielded twisted pair wire. The maximum length of this connection is 1000 feet.

Wire size is an important consideration when making the connections between the fire protection system control package and a gas valve. Refer to **Table 11** for maximum wiring distance between the system and remote gas valve.

Table 11 - Wiring Maximum Distance


Wire Gauge	Distance (Feet)
12	1049
14	660
16	414
18	260
20	164
22	103
24	64

Fire Alarm Contacts

The fire protection system is equipped with optional normally open contacts (terminals **AL1** and **AL2**) for building applications that connect to the premise Fire Alarm Control Panel (FACP). Refer to **Figure 44** for wiring reference. During a fire condition, the contacts will close and trigger the premise FACP to initiate a general fire alarm.

Figure 44 - Fire Alarm Reference

1. Building Fire Alarm
2. Control Panel Fire Alarm Contact
3. End of Line Device
4. Alarm Input



Fire Group

Fire Groups are for the purpose of using multiple CORE controlled fire systems and grouping specific fire systems together. This will allow the user the ability to assign different zones for independent activation.

In order to set a fire group, you will need to set the CORE board DIP switches as shown in **Table 12**.

Table 12 - Fire Group DIP Switch Position

6	7	Fire Group Number
Off	Off	1
On	Off	2
Off	On	3
On	On	4


Note: Every panel with matching fire group settings (DIP switches 6 and 7) will activate simultaneously in a fire condition.

Figure 45 shows an example of different zones on separate fire groups, but still connected via the interlock network. In the example, when 2 Fire groups (01 and 02) are assigned on the CORE boards, and if a fire condition exists in any one group, it will NOT activate the other fire group. However, both are connected to the same interlock network.

- Fire Group 01 CORE board DIP switch setting will be set to: Switch 6 Off and Switch 7 Off.
- Fire Group 02 CORE board DIP switch setting will be set to: Switch 6 On and Switch 7 Off.

Refer to “**DIP Switch Settings**” on page 63 for setting multiple CORE controlled fire systems.

Figure 45 - Fire Group Reference



Fire Protection System Supervised Loops


The supervised loops are integral to proper operation and activation of the Fire Protection System. All systems have two supervised loops; each loop consists of two conductors, one positive and one negative. One loop is dedicated to all sensors, while the other is dedicated to all manual actuation devices (push/pull stations). The supervised loop connections are located at the front edge of the hoods for accessibility. Connections beyond the hood, like the connections at the manual actuation device, must be made with a plenum-rated wire. It is recommended to use a two-conductor Belden 6320UL, 18 AWG, wire, or similar for these connections. Refer to **Figure 46** for supervised loop details.

The supervised loop must be run through metallic conduit. Do not run wiring with high voltage wires. Verify all supervised loop wires are free from damage/stress. All supervised loop wires must be terminated in terminal blocks, junction boxes, and push-stations.

- Connections to the firestat will use two Wago connectors. One for an incoming loop and one for an outgoing loop.
- Flexible metallic conduit is used to route the wiring that connects the firestat to the remote loop junction box. Secure conduit to hood hat channel when possible.

Figure 46 - Supervised Loop Connections

- 1. Firestat
- 2. Conduit
- 3. Junction Box
- 4. Wago Connector



For connections on or above the hood, use Type MG or MGT wiring with Wago connectors. A Supervised Loop Connection kit is available to connect back to back or end to end hoods. This kit will come with the necessary hardware and wire.

Table 13 - Supervised Loop Components

Connection Kit Part Number	Length	Location
SLPCON-03	3 Feet	End to End Hoods
SLPCON-05	5 Feet	End to End Hoods
SLPCON-10	10 Feet	End to End and Back to Back Hoods
SLPCON-15	15 Feet	End to End and Back to Back Hoods
SLPCON-20	20 Feet	End to End and Back to Back Hoods

High Temperature Supervised Loop Components	Part Number
Type MG Wire, White, 16 AWG	441601C6.FE9
Type MG Wire, Black, 16 AWG	441601C6.FE0
Wago Connectors	221-412

Supervised Loop Electrical Details

NOTE: Place the panel in test mode when checking the supervised loop circuit.

Before checking the supervised loop circuit (**Figure 47**), verify all CORE power supplies (PS-02) are set to 27.5V +/- 0.1V DC. Check all supervised loop connections. Verify wiring is properly connected and secure. If any of the readings in **Table 14** are out of range or other faults are present, there is an issue with that loop or associated components/wiring. Refer to **page 62** for troubleshooting.

Figure 47 - Wiring for Supervised Loop




Table 14 - Supervised Loop Circuit Readings

Component Check	Procedure: Check for continuity between terminals. Place the breaker off. Disconnect the batteries at connector J1	Expected Readings
Firestat(s)	Terminals 21 and 24; Terminals 22 and 23	Continuity
	Terminals 21 and 22; Terminals 21 and 23 Terminals 24 and 23; Terminals 24 and 22	No Continuity
Manual Activation Device (MAD)	Terminals 101 and 104; 102 and 103	Continuity
	Terminals 101 and 102; Terminals 101 and 103 Terminals 104 and 103; Terminals 104 and 102	No Continuity
Component Check	Procedure: Measure voltage between terminals. Place the breaker on. Reconnect the batteries at connector J1	Expected Readings
Power Supply	PS-02 (DC+) and PS-02 (DC-)	27.5 +/- 0.1V DC
Firestat(s)	PS-02 (DC-) and Terminal 21; PS-02 (DC-) and Terminal 24 Terminal 21 and Terminal 22; Terminal 23 and Terminal 24	26.5 +/- 0.2V DC
	PS-02 (DC-) and Terminal 22; PS-02 (DC-) and Terminal 23	0 +/- 0.2V DC
	Terminal 24 and Chassis Ground	1.8 +/- 0.2V DC
Manual Activation Device (MAD)	PS-02 (DC-) and Terminal 101; PS-02 (DC-) and Terminal 104 Terminal 101 and Terminal 102; Terminal 103 and Terminal 104	26.5 +/- 0.2V DC
	PS-02 (DC-) and Terminal 102; PS-02 (DC-) and Terminal 103	0 +/- 0.2V DC
	Terminal 104 and Chassis Ground	1.8 +/- 0.2V DC

PCU Fire System

Pollution Control Units require a fire system to be installed for Type 1 applications. Current International Mechanical Code (IMC) requires that the fire system be installed by the manufacturer (2018 IMC). CORE and EWC fire systems are available for the PCU. PCU fire systems use electric sensors set at 360°F to activate the fire system. Outdoor EWC Systems require a climate controlled utility cabinet to ensure that the fire system does not drop below 32°F and does not exceed 130°F. See below for more information about outdoor installations. It is highly recommended that the PCU fire system be interlocked to the corresponding hood fire system so that if the hood system activates, the PCU system activates. Reverse activation requirements are determined by local code or at the discretion of the Authority Having Jurisdiction, but are recommended for safety.

In the event that the fire system is accidentally activated, all disposable filters must be replaced and the pre-filter cleaned. The water or chemical agent used in the fire system can cause the filters to fail prematurely.

In the event that a fire occurs in the ductwork leading to the PCU or inside the PCU, the following must be completed.

- The unit must be cleaned of all fire suppression chemicals and grease.
- The filters must be replaced, this includes the pre-filter.
- If an ESP module is present, the ESP cells must be removed, and cleaned in warm soapy water. Wash cells until all chemical residue is removed. ESP pre and post filters must be replaced. When re-installing cell(s), make sure to install with the **airflow in the correct direction** as indicated on the cell.
- If any of the gasketing is damaged, replace the gasketing between modules and between the doors.
- If any of the components that make-up the Pollution Control Unit are damaged by fire, then that component must be replaced and inspected by factory trained service personnel.

Installation, commissioning, or resetting of the fire system must be done by a licensed fire system installer. Use the guidelines set forth by the appropriate fire system manual; PCU with CORE Fire Suppression System manual, Model TANK (Electric Wet Chemical) Extinguishing System, or other fire system manufacturer.

For electric wet chemical fire systems for PCU, external piping that connects the PCU fire system nozzles to the fire system tanks is factory-installed using Grade L 1/2" copper tubing and pro-press fittings. If a remote (wall mount) EWC fire system is utilized, distribution piping shall be Grade L 1/2" copper tubing and pro-press fittings or 3/8" NPT Schedule 40 black iron, chrome-plated, or stainless-steel pipe and fittings. If distribution piping is exposed to an outdoor environment it must be Grade L 1/2" copper tubing and pro-press fittings or 3/8" NPT Schedule 40 stainless-steel pipe and fittings.


PCU Fire System Nozzles

The Overlapping Male Nozzle(s) (p/n OL-M) are used to protect the PCU.

The nozzles include a cap (p/n 3074-1-1).

Refer to **Figure 48**. The cap prevents contamination from entering the pipe network and is designed to pop-off upon system discharge, allowing the fire system to flow to the protected hazard area.

Figure 48 - Fire System Nozzle



Nozzle P/N: OL-M

Previously P/N: 3070-3/8HH-10-SS

Table 15 provides details on PCU size, modules, and nozzle quantity per unit. Pollution Control Units (PCU) covered by a TANK Fire System can utilize up to 12 nozzles per tank.

PCU Fire System type "REFS" is covered by TANK.

Table 15 - PCU Fire System Chart

PCU Size	Unit Nozzle Count (OL-M)					Duct Nozzle Count (OL-M) Last Module Only
	1 Module	2 Modules	3 Modules	4 Modules	5 Modules	
1	4	8	12	16	20	2
2	4	8	12	16	20	4
3	5	10	15	20	25	4
4	6	12	18	24	30	4
5	7	14	21	28	35	4
6	7	14	21	28	35	6
7	11	22	33	44	55	6

Example:

Model - PCU-PF-HE-ESP-OC-XXXX-5



Number of Modules - 4

PCU Size - 5

Number of OL-M Unit Nozzles - 28

Number of OL-M Duct Nozzles - 4

Total Nozzles - 32

OPERATION

The TANK Fire Suppression extinguishing system is electrically operated via the onboard controls and may be electrically interlocked with a fire alarm control panel (when present). The system can be activated automatically via a Firestat or manually via a remote manual actuator. Since the TANK Fire Suppression extinguishing system is electrically operated, the system requires AC input power with a battery backup system. Reference the job specific wiring schematics.

When one of the system's Firestat(s) detectors senses a temperature hotter than its internal set-point (e.g., in the event of a hood fire), or when a remote manual actuation device (push/pull station) is pushed, an electric signal is sent to the tank-based fire protection release solenoid via the fire alarm control panel releasing circuit. The electric release solenoid is energized, allowing pressurization of the pneumatic actuator(s). The actuator's plunger(s) will depress into the tank valve body, releasing agent to flow to the hood duct, plenum, and appliance nozzles.

When the fire extinguishing system is activated, the applicable fire alarm control panel simultaneously shuts down all gas and electric appliances under the protected hood(s), shuts down make-up air and/or exhaust where applicable, and activates the building fire alarm where applicable.


The electrically operated fire system requires a battery backup system. In the event of a loss of building electrical power, all gas and electric appliances under the hood must be electrically interlocked to shut off. This is achieved via a gas valve relay and/or a shunt trip breaker. The battery backup will automatically energize upon a loss of power. The battery backup will monitor the fire system circuit for up to 24 hours and be able to operate the fire system circuit for a minimum of 30 minutes. Once power is restored, the battery will automatically recharge.

A means of manual reset is required for shut-off devices to ensure manual reset prior to fuel or power being restored in accordance with NFPA 17 and NFPA 96. The electric gas shut-off valve is used in conjunction with a UL/ULC listed manual reset relay, refer to **"Gas Shut-Off Valves" on page 40**.

Appliance and electrical shut down is achieved via the applicable fire alarm control panel relay, in conjunction with UL/ULC listed enclosed industrial control equipment or magnetic contactors of appropriate rating. These must be used in conjunction with a UL/ULC listed manual reset relay, refer to **Figure 49**. All wiring is to be in accordance with the applicable manufacturer's instructions for the fire alarm control panel, gas shut-off valve, manual reset relay, and contractor supplied shut-off devices. All wiring must be in accordance to NFPA 70 and the Authority Having Jurisdiction (AHJ).

The TANK Fire Suppression System is not required to be interlocked to a building's fire alarm control panel to function. When a building fire alarm system is present, the fire alarm control panel may be connected such that the actuation of the TANK Fire Suppression extinguishing system also activates the fire alarm. Reference the applicable control panel manual for wiring and compatibility.

Figure 49 - Reset Relay



Test Mode Overview

The fire protection system has an integrated option for testing. When in test mode, the release solenoid is disabled and will prevent the fire extinguishing agent from spraying on the appliances. For testing purposes, this will allow the activation of the fire system, audible alarm, shunt trip breaker (if applicable), and shut down of appliances via gas valve reset relay.

All additional PCBCORE controlled packages that are attached to the system must be in “Test” mode. This includes additional fire protection systems, Pollution Control Unit with CORE, and other hood-mounted CORE controlled protection systems.

Please note that the appliances must be started before test mode is entered on any PCBCORE protection package for proper demonstration of this function. If the fire protection system is left in “Test” mode for more than 15 minutes, the appliances will shut down. This is to prevent cooking operations from occurring while the appliances and ventilation system are not protected.

ATTENTION: All interlocked PCBCORE controlled packages must be placed into “Test” mode before cleaning the hood, Pollution Control Unit (PCU), or any other interlocked units.

Reset Overview

There are multiple actions required to reset the fire system. **The following must be completed by a Certified Fire System Technician.**


1. The duct firestat must be cooled below its internal set point.
2. The remote manual actuation device (push/pull station) must be reset by twisting the button clockwise until it resets.
3. Press the “Push To Reset Fire System” button.
4. Reset the pneumatic actuators (PAK, SVA), refer to “**Re-arming System**” on page 69.

Note: The firestat must be cool, and the remote manual actuation device (push/pull station) must be reset for this button to work.

The fire system must be re-commissioned per the manufacturer’s recommendations and guidelines by an authorized fire system distributor and/or authorized service agent.

WARNING: In the event of an actual fire, further inspections are required after the fire has been extinguished to verify the integrity of the hood, ductwork, fire sensors, fan, and fire suppression system has not been compromised. With approval from the Authority Having Jurisdiction (AHJ) or the Fire Department, proceed to restarting the fire system.

Figure 50 - Fire System Reset



Battery Backup

Important!

The battery backup system requires that the batteries be changed every 2 years, from the date of fire system commissioning, maximum. Failure to do this will result in a void in product reliability and may cause severe damage to facility due to loss of fire protection.


The fire protection system contains a battery backup. During a power loss, the "Fire System Status" light will flash 11 times between pauses indicating the power loss.

The batteries must be replaced every 2 years, from the date of fire system commissioning. Part number PS-1270-F2, two are required. Although the batteries are hot-swappable, which means they can be replaced while there is input power to the control, **for your safety, all sources of power must be removed from the control before replacing the batteries.** To replace the batteries, unplug the battery cable from the J1 connector on the electrical board (PCBCORE). Then remove the retaining strap holding the batteries in place. Remove the batteries from the cabinet. Transfer the fuse and cable set from the old batteries to the new batteries being extremely careful to observe the RED and BLACK lead and terminal colors. Reinstall the batteries in the cabinet and reconnect the battery plug to J1. The batteries are lead-acid type and are recyclable; **please dispose of the old batteries properly.**

During extended periods of inactivity where the fire protection system will be without AC power for more than 2 days, such as a shutdown or natural disaster, it is best to decommission the fire system by disconnecting the batteries. This will prevent any damage to the batteries through complete discharge. When the system becomes active again, commission the system by reconnecting the batteries and allow the batteries to charge for 48 hours.

The fire protection system is supplied with 14-amp hours of backup battery capacity. Per NFPA 72 10.5.6.3, the system requires 1.66 amp hours of battery capacity.


Figure 51 - Battery Backup



Power Supply Adjustment

To properly charge the batteries, the power supply must be adjusted to output 27.5V DC. This can be checked with an accurate digital voltmeter placed across Terminals H1D and N1D. To adjust the output voltage, place a small flat-bladed screwdriver into the yellow dial. Turn the dial clockwise, this will increase the voltage.

Figure 52 - Power Supply



Fire Protection System Firestat

The Firestat (page 42) is a device installed in the riser of the hood, at the duct connection, that measures temperature. One sensor shall be installed in each exhaust riser. Secondary downstream detectors in the duct are not required except as outlined in the **Non-Solid Fuel Appliances** and **Solid Fuel Appliances** section. Sensors are not required above each appliance or in the hood grease plenum. The standard temperature setting is 360°F. Depending on heat produced by appliance, a higher rated temperature Firestat will be required. If a temperature higher than the setpoint is sensed, the Firestat contacts will close and energize the electrical control board. The fire system will activate.

The supervised loop must be run through metallic conduit. Do not run wiring with high voltage wires. Verify all supervised loop wires are free from damage/stress. All supervised loop wires must be terminated in terminal blocks, junction boxes, and push-stations.

The Firestat has 2 black wires and 2 white wires. These wires must be connected to the supervised loop. Use high-temperature wiring when installing Firestat components. Wago connectors (part number: 221-412) must be used.

Multiple sensors are wired in parallel in the supervised loop. The Firestat may be installed on the opposite side of the quick seal for access in the duct.

Non-Solid Fuel Hood/Appliances (Rated 450°F)

Light and Medium duty, non-solid fuel appliances with a cooking surface temperature rated for 450°F will not require additional firestats, regardless of the configuration and length of ductwork.

Non-Solid Fuel Hood/Appliances (Rated 600°F)

Heavy duty, non-solid fuel appliances with a cooking surface temperature rated for 600°F will require downstream detection if the duct run contains any horizontal section over 25 feet in length. Downstream detection should be installed at the end of a horizontal section. Duct layouts that include less than 25 feet of horizontal ductwork will not require additional detection.

Solid Fuel Hood/Appliances (Rated 700°F)

Extra Heavy duty, solid fuel appliances with a cooking surface temperature rated for 700°F will require 600°F rated Firestats, and SOLO filters. Exhaust fan(s) used with solid fuel appliances must use a steel wheel.

Solid fuel produces effluents that can accumulate inside the duct, especially in long horizontal duct runs. Sparks from solid fuel cooking can travel into the ductwork and create fires that occur beyond the point where the hood riser Firestat can detect them. Additional downstream Firestats ensure that these duct fires are detected and the fire system actuates.

In addition to the 600°F rated Firestat, located in the hood riser, a second Firestat is required at the duct discharge for solid fuel applications when the ductwork exceeds 10 feet in length or contains horizontal runs. Even if the entire duct run is inaccessible, this additional Firestat is still needed. Mounting a Firestat in the fan may be an option. On duct runs longer than 50 feet, a third Firestat will be required somewhere in the duct run, ideally at the end of a horizontal run, if present. Duct runs longer than 100 feet will require additional Firestats, **contact your local sales office for more information.**

NOTE: When additional Firestats are required, install in an accessible location near an access door, hood riser, or fan. The door will provide access to install, clean, and replace the Firestat when needed. If a PCU is equipped with electronic detection, PCU Firestats can serve as downstream detectors, if present. The temperature rating of the Firestat in the duct must always match the temperature rating of the Firestat in the riser.

TROUBLESHOOTING

Table 16 lists out causes and corrective actions for possible problems with the system. Review this list prior to consulting the manufacturer.

Table 16 - Fire Protection System Troubleshooting

Problem	Potential Cause	Corrective Action
Exhaust Fan is On and Supply Fan will not Start	Broken supply fan belt	Replace fan belt.
	Fire system not armed	Fire system distributor must arm fire system.
Fire System Status Light On	Fire system is activated	Verify fire is out and reset fire system.
Audible Alarm is On	Fire system is activated	Verify fire is out and reset fire system.
A fault code is flashing on the "Fire System Status" light	A fault has been detected in the Fire Protection System	Count the flashes and refer to "Appliance Shutdown in Fault Conditions" on page 61.
Gas Valve does not Close	Debris on gas valve seal	Fully clean gas valve and strainer.
Fire System will not Turn Off	Duct sensor is hot	Heat has activated the duct sensor. Remove heat source or let the system extinguish the fire. Once heat source or problem is resolved, press reset button on the face of the electrical control package.
	Remote Manual Actuation Device has been pushed	Reset remote push station once fire is out and press reset button on the face of the electrical control package. Reset remote push station by twisting clockwise until reset.

CORE Board Faults

When there are no faults in the fire system, Lamp B will stay solid (An LED indicator is also on the control package). When a fault exists, the LED will flash with a short break. Count the flashes then wait for a short break to determine the fault. For packages with HMIs, refer to the fault displayed on the screen. For fault operation in shut down, refer to **“Appliance Shutdown in Fault Conditions” on page 61.**

NOTE: CORE Boards with software versions 1.68 and prior will use one brief flash every 3-seconds to indicate there is no fault.

Test Mode allows the system to be tested with operational appliances without discharging the system. If the system is left in test mode for 15 minutes, the gas valve will be locked out until test mode is deactivated.

Flashes	Fault Condition	Corrective Action
Catastrophic Faults		
1	Invalid Activation*	Check for external voltage being applied at J3-7 and J3-10.
2	Release Solenoid*	Check solenoid and wiring to solenoid, replace as needed.
3	Pressure Switch*	Check switch and wiring to switch, replace as needed.
4	N/A	N/A
5	Microcontroller Fault*	Replace CORE printed circuit board.
Critical Faults		
6	N/A	N/A
7	Supervised Loop Fault*	Check the installation of the wiring to all the manual actuation devices (push stations) and firestats. Verify connections are secure and tight. Check for open/short circuits in the wiring. Repair or replace wiring as needed.
Important Faults		
8	Ground Fault	Check the installation of the wiring to all the manual actuation devices (push stations) and firestats. Verify connections are secure and tight. Check for open/short circuits in the wiring. Repair or replace wiring as needed.
9	N/A	N/A
10	Battery Voltage Low	The voltage is below the battery threshold. Wait for batteries to recharge if there was a power failure. Replace if the batteries will not hold a charge.
11	AC Power Failure*	The voltage is below the power supply (PS-02) threshold; approximately 27.18V DC. Check breakers, call power company.
12	Door Tamper Switch	Close cabinet door.
13	Test Mode*	Place switch in armed position when testing is complete.
14	CORE Interlock	Check Dip Switches on all boards and RS-485 network wires connecting boards.
15	Fault on Hood in Network	Check all hoods in CORE network for faults.
16	Fault on PCU in Network	Check all PCUs in CORE network for faults.

NOTE: The low pressure switch option is not required per product safety listings and standards. The fault is for monitoring purposes. When a Pressure Switch or Supervised Loop fault is present for 24 hours, cooking operations will shut down.

Faults marked with (*) will shut down Gas/Shunt. During an AC power failure or loss of building power, all 120V AC gas valves/electrical appliances will shut down immediately. For 24V DC gas valves, the valve will stay powered for a few minutes depending on battery voltage (when both an AC Power Failure and Battery Voltage Low fault are present, the valve will shut down).

Appliance Shutdown in Fault Conditions

The system is equipped to shut down the appliances if a fault condition is present. **Table 17** displays fault conditions that affect the appliances' fuel and power sources, alarm muting, and local trouble relay.

NOTE: CORE Boards with software version 1.68 and prior will use one brief flash every 3-seconds to indicate there are no faults in the fire system.

Table 17 - Appliance Fault Conditions

Number of Flashes	Fault Condition	Gas Valve Shutdown		Shutdown Shunt Trip Breaker and UDS Kill Switch		Mute Local Alarm 4 Hour Reset	Local Trouble Relay
		Local System	Networked System	Local System	Networked System		
Catastrophic Faults							
1	Invalid Activation*	X	X	X	X		X
2	Release Solenoid*	X	X	X	X		X
3	Pressure Switch*	X	X	X	X		X
4	N/A	-	-	-	-	-	-
5	Microcontroller Fault*	X	X	X	X		
Critical Faults							
6	N/A	-	-	-	-	-	-
7	Supervised Loop Fault	X	X	X	X		X
Important Faults							
8	Ground Fault					X	
9	N/A	-	-	-	-	-	-
10	Battery Voltage Low					X	X
11	AC Power Failure*	X	X	X	X		X
12	Door Tamper Switch					X	
13	Test Mode*	X	X	X	X		
14	CORE Interlock					X	
15	Fault on Hood in Network					X	
16	Fault on PCU in Network					X	

NOTE: The low pressure switch option is not required per product safety listings and standards. The fault is for monitoring purposes. When a Pressure Switch or Supervised Loop fault is present for 24 hours, cooking operations will shut down.

Faults marked with (*) will shut down Gas/Shunt. During an AC power failure or loss of building power, all 120V AC gas valves/electrical appliances will shut down immediately. For 24V DC gas valves, the valve will stay powered for a few minutes depending on battery voltage (when both an AC Power Failure and Battery Voltage Low fault are present, the valve will shut down).

Local Alarm Muting

Pressing the fire system reset button can mute the local alarm. This will disable the sounder for 4 hours under specific conditions. **Table 17** shows which faults can be muted. It should be noted that the fault will not clear until the fault condition is corrected.

Test Mode

Test Mode allows the system to be tested with operational appliances without discharging the system on the appliances. Once the appliances are started, test mode can be entered without the appliances shutting down for 15 minutes. However, once the fire system is activated, the shunt trip (electric appliances) and the gas valve will be locked out until test mode is deactivated.

Supervised Loop/Power Supply Troubleshooting

NOTE: Place the panel in test mode during diagnostic testing.

Before troubleshooting, verify all power supplies (PS-02) are set to 27.5V DC. Verify all circuit checks from **“Supervised Loop Electrical Details” on page 52**. If any readings are not in range, there is an issue with that loop or associated components/wiring. Refer to **Table 18** for troubleshooting.

Table 18 - Common Wiring Troubleshooting Chart

Problem	Potential Cause	Expected Results +/- 0.2	Corrective Action
Supervised Loop Fault	Open Supervised Loop between Terminals 21 and 24.	<ul style="list-style-type: none"> Terminal 21 to PS-02 (DC-) = 26.5V DC Terminal 21 to Terminal 22 = 26.5V DC Terminal 24 to PS-02 (DC-) = 26.5V DC Terminal 24 to Ground = 1.8V DC 	Locate and repair faulty wiring in the 21-24 supervised loop.
	Open Supervised Loop between Terminals 22 and 23.	<ul style="list-style-type: none"> Terminal 22 to PS-02 (DC-) = 0V DC Terminal 23 to PS-02 (DC-) = 0V DC Terminal 23 to Terminal 24 = 26.5V DC 	Locate and repair faulty wiring in the 22-23 supervised loop.
	Open Supervised Loop Push-Station (Terminals 101 and 104)	<ul style="list-style-type: none"> Terminal 101 to PS-02 (DC-) = 26.5V DC Terminal 101 to Terminal 102 = 26.5V DC Terminal 104 to PS-02 (DC-) = 26.5V DC Terminal 104 to Ground = 1.8V DC 	Locate and repair faulty wiring in the 101-104 supervised loop.
	Open Supervised Loop Push-Station (Terminals 102 and 103)	<ul style="list-style-type: none"> Terminal 102 to PS-02 (DC-) = 0V DC Terminal 103 to PS-02 (DC-) = 0V DC Terminal 103 to Terminal 104 = 26.5V DC 	Locate and repair faulty wiring in the 102-103 supervised loop.
Ground Fault	Terminals 22 or 23 are shorted to chassis ground. *24V DC PS-02 (DC-) Wiring or Components.	Chassis Ground to PS-02 (DC-) = 24.4V DC	Locate and repair shorted wiring between 22-23 supervised loop and ground.
	Terminals 21 or 24 are shorted to chassis ground. **24V DC PS-02 (DC+) Wiring or Components.	Chassis Ground to PS-02 (DC+) = 2.7V DC	Locate and repair shorted wiring between 21-24 supervised loop and ground.
	Interlock Network Issue	Check battery voltage and supervised loop wiring with other packages that are interlocked in the network.	Locate and repair faulty wiring in the circuit. Replace batteries.
AC Power Failure	120V AC Input Power Supply Interrupted.	H1 to N1 = 110V to 125V AC	Verify constant input power between H1 and N1. Check wiring to L/N terminals on PS-02. Locate and repair faulty wiring in the circuit.
Battery Voltage Low	Faulty Battery or Power Supply (PS-02).	J1-1 to J1-2 = 23.5V to 24.5V DC	Verify there is 12V DC to each battery connection. Locate and repair faulty wiring in the circuit. Replace batteries.
	Interlock Network Issue.	Check battery voltage and supervised loop wiring with other packages that are interlocked in the network.	Locate and repair faulty wiring in the circuit. Replace batteries.
Release Solenoid	Solenoid wiring incorrect.	Check RS to N1D when: <ul style="list-style-type: none"> Wire removed from RS terminal = 15.5DC V +/- 2V RS terminal wired, connector removed = 6.5DC V +/- 2V RS terminal wired, connector installed = 0.2-0.4DC V 	Check wiring at terminals. Locate and repair faulty wiring in the circuit.
	Connector is not secured to solenoid.		Verify the connector is secured to the valve.

*** Components that may cause this fault are: Gas Valve, Surfactant Pump, Water Solenoid(s), Release Solenoid(s).**

**** Components that may cause this fault are: 24V Relays, Trouble Relay (when energized), 24V LED Lights.**

NOTE: If an abnormal reading is present, disconnect potential components/wiring one at a time, while continuing to take readings, to locate the source of the ground fault.

DIP Switch Settings

When a network contains a single CORE Board, DIP switches 1, 5, and 8 are in the On (Closed) positions and 2, 3, 4, 6, 7 are in the Off (Open) positions (**Figure 53**). This is the default positions and should not be changed. **Table 19** provides DIP switch settings for CORE Boards interlocked in a network.

Figure 53 - Single CORE Board Network DIP Switch Settings




Table 19 - DIP Switch Settings

Interlock Board Address #	DIP 1	DIP 2	DIP 3	DIP 4
1	On	Off	Off	Off
2	Off	On	Off	Off
3	On	On	Off	Off
4	Off	Off	On	Off
5	On	Off	On	Off
6	Off	On	On	Off
7	On	On	On	Off
8	Off	Off	Off	On
9	On	Off	Off	On
10	Off	On	Off	On
11	On	On	Off	On
12	Off	Off	On	On
13	On	Off	On	On
14	Off	On	On	On
15	On	On	On	On

Each unit has a unique address based on the DIP switch 1-4 settings, 15 units max on a network. If address is 0 (all switches off), the unit will not accept or send any network traffic

DIP 5

DIP Switch 5 sets the Master Board when this is set to On (Closed). The Master Board must be the highest address on the interlocked network. Otherwise, this switch must be Off (Open). The Master CORE Board must be the only CORE Board connected to an ECPM03 Board via a CAT-5 cable. Refer to **Figure 55**.

Fire Group #	DIP 6	DIP 7
1	Off	Off
2	On	Off
3	Off	On
4	On	On

DIP Switches 6 and 7 set the Fire Group. You may only have four Fire Groups. Refer to **page 50** for more information on fire groups.


DIP 8

Setting switch 8 to the On (Closed) position connects a 120 Ohm terminating resistor to the interlock network. This switch must be On if this unit is at either physical end of the interlock network cable. Otherwise, it must be Off (Open).

- When DIP switch 5 is On, this will be the “Master” board. It will be in charge of polling all the units in the network and waiting for a reply. The lack of 3 replies in a row will cause a fault. All units will be polled in a burst every 3 seconds.
- Non-master units, the lack of being polled for 10 seconds will cause a fault.
- A fire condition will broadcast the notification once every second for as long as the condition persists.
- When the Fire condition is cleared, 10 notifications will be sent, one every second.
- Any unit detecting a supervisory fault will broadcast the notification every 2 seconds until the fault is cleared.
- When the supervisory fault condition is cleared, 10 notifications will be sent, one every 2 seconds.


NOTE: CORE Boards with a Red DIP Switch block use Open/Closed positions. When verifying switch configurations; On = Closed/Off = Open.

Figure 54 - Interlocked DIP Switch Examples



The Master CORE Board must be the only CORE Board connected to an ECPM03 Board via a CAT-5 cable. All other CORE Boards in the interlocked network will be field wired to terminals CA, CB, CC.

Figure 55 - ECPM03 Connection to CORE Board



START-UP/INSPECTION TEST PROCEDURE

NOTE: This service procedure covers a single manifold system however a duplicate manifold and tank setup is possible. If you have a two manifold system, a second service kit will be required along with fittings to connect it properly. Refer to Table 23 on page 83 for service parts.

Required Tools:

- Precision Slotted Screwdriver
- Heat Gun (field supplied) and Heat Gun Deflector (Part# 33M674 or 33M679)
- Nitrogen Service Kit - single manifold only
- Balloons
- Warm Soapy Water
- 1/4" SAE Tee Connector with cap and valve core. 1/4" female knurl and 1/4" SAE male connections. Used for multiple manifold systems only.
- Micro Leak Detector
- In-Line Filter
- Digital Pressure Gauge

CAUTION!: Never use magnetic tools or cause excessive vibration when the actuators are bolted to the cylinder(s).

Parts:

- Supervised Loop Wiring: Black Wire - Part #: 441601C6.FE0 & White Wire - Part #: 441601C6.FE9
- Push Station Wiring: Belden Wire - Part #: 6320UL (or similar)
- WAGO connectors - Part #: 221-412
- Replacement PAK O-rings

Fire System Wiring Connections

- Connect the Manual Activation Device (MAD) using Belden #6320UL, 18 Gauge plenum rated wire.
- Connect all Firestats using Belden #6320UL (or similar), 18 Gauge plenum high temperature rated wire. Single hood systems with a hood mounted utility cabinet may not have any additional stats.
- **The supervised loop must be run through metallic conduit.** Do not run wiring with high voltage wires. Verify all supervised loop wires are free from damage/stress. All supervised loop wires must be terminated in terminal blocks, junction boxes, and push-stations.
- Install the 24V DC or 120V AC gas valve.
- Verify that all solenoid wires and electrical control panel wiring are secured. Any supervised loop wiring within 18 inches of the top of the hood must be high-temp wire, type MG or MGT with WAGO connectors (Part # 221-412). Type MG White (Part # 441601C6.FE0), Type MG Black (Part # 441601C6.FE9).

Preparing System for Test

- **Place all building alarm systems in test mode. Place the electric control panel in "Test" mode. Refer to Figure 56. Verify there are no supervision faults on the HMI.**
- Verify that the hood, duct, and kitchen appliances have not changed (including type, dimensions, and location) from the approved design. **Appliance drops must be between 35-50 inches from the hazard surface.**
- Verify that all cylinder discharge outlets are connected to the system.
- Verify that all cylinders are secured in their bracket(s).
- Verify that a valve cap or supervisory pressure switch (optional) is installed on each secondary cylinder Schrader valve.
- Verify that nozzle caps are installed.

NOTE: If this is the first service after installation, the PAK hose should be disconnected, and the primary and secondary valve actuators should be in the ship/test position. Refer to Figure 57 on page 66.

Figure 56 - Electric Control Panel "Test" Mode

APPLIANCE PROTECTION
TEST ARMED



PUSH TO RESET
FIRE SYSTEM



Connecting Service Test Kit

WARNING!

If the PAK or SVAs are installed on the cylinder valve during the test, the cylinders will discharge.

CAUTION!: Supplied Nitrogen Pressure Shall Not Exceed 250 psig Maximum.

NOTE: The PAK hose is shipped disconnected, and the PAK/SVA(s) are shipped in the Ship/Test position


- Check the quantity of Schrader valves on the tank cylinder assembly.
 - Tank assemblies with one Schrader valve:
 - Quickly disconnect the PAK hose to minimize nitrogen loss. Verify a Supervisory Pressure Switch is active on the HMI. If the electrical package is interlocked, the HMI will show “Test Mode.”
 - Tank assemblies with dual Schrader valves:
 - **If this is the first installation/start-up procedure, confirm a Supervisory Pressure Switch fault is active.** Then, connect the PAK hose to the tank Schrader valve after the PAK/SVA actuators are confirmed in the ship/test position.
 - **NEVER DISCONNECT the PAK hose from the tank during normal 6-month inspections. The primary tank secondary Schrader valve will be utilized for servicing the system.** A Supervisory Pressure Switch fault should not be active on the HMI.

NOTE: PAK hoses with knurled fitting must ONLY be tightened by hand and not with a tool. If the PAK hose with a hex fitting was loosened for any reason, this fitting must be torqued to 15 in-lbs.

- Remove the PAK and any Secondary Valve Actuators (SVA) from their cylinder. Place PAK and SVAs in the ship/test position. Verify that the PAK and SVAs are securely mounted to the bracket. Refer to **Figure 57**.

Figure 57 - System Preparation

1. Primary Supervisory Pressure Switch
2. PAK Hose Disconnected
3. Secondary Supervisory Pressure Switch (optional)
4. PAK/SVA in the Ship/Test Position



- Connect the Nitrogen Service Cylinder via the 1/4" refrigerant test hose with an inline filter. If the filter has a directional airflow arrow, verify correct orientation. Refer to **Figure 58 on page 67**.
 - For a single Schrader valve, connect the PAK hose to the inline filter.
 - For dual Schrader valves, connect a secondary 1/4" refrigerant test hose to the open secondary tank Schrader valve. Connect the end of the hose to the filter.
- Verify that the pistons in the PAK and SVAs are in the set position. The plunger is not actuated. Refer to **Figure 60 on page 68**.
- Connect a 1/4" pressure gauge to the Schrader service valve of the PAK assembly. Verify the pressure reads 0 psi. Refer to **Figure 58**.
- Verify all secondary actuator hoses are connected to the appropriate PAK/SVAs. Tighten connections.
- Verify the actuation line vent limiting orifice is installed and tight in the last actuator on the system (last SVA or PAK if there are no secondary cylinders). **Do not use pipe dope or tape on the orifice.**
- Verify that the Primary Supervisory Pressure Switch is installed securely on the PAK. **Torque to 75 in-lbs.**
 - Optional Feature: Secondary tanks may also have Supervisory Pressure Switches installed, verify all switches are properly secured to all secondary tanks. **Torque to 75 in-lbs.**
- Verify the PAK solenoid is de-energized.
 - Open the Nitrogen Cylinder. Adjust the pressure to 225 psig.
 - Monitor the pressure gauge on the PAK. The pressure must not read above 0.5 psi for 15 minutes. This indicates the primary actuator solenoid is in the de-energized state and will not let pressure through as intended. The gauge may fluctuate between 0 and 0.5 psi.


CAUTION!: If pressure reads above 0.5 psi. Submit a ticket to through technical support. Refer to “Technical Support Information” on page 84.

- Place the system in “Armed” mode.
- Lift the cover to the manual activation device and “push” to activate the fire system.
- Verify all PAK and all SVAs have actuated. The piston should be fully extended and in a locked position. Refer to **Figure 58**.
- Verify that there are no leaks in the actuation line. Nitrogen will pass through the vent limiting orifice.
- Verify that the solenoid is in the energized state.
 - Monitor the pressure gauge on the PAK. When the fire system is activated, the pressure should be 185 psi or higher. This indicates the system is functioning and will let pressure through as intended.

CAUTION!: If pressure reads under 185 psi. Submit a ticket to through technical support. Refer to “Technical Support Information” on page 84.

- If all of the above is confirmed, reset the control panel. The manual activation device can be reset by twisting the push button in a clockwise motion. Press the “Push To Reset” button. Place system in “Test” mode.
- Reset plungers in the PAK and SVAs to their set position.
- Close the Nitrogen Cylinder.
- Remove the pressure gauge on the PAK.

Figure 58 - Service Test Tank Details



NOTE: Pressure gauge minimum requirements; 1/4" female flare, 0-250 psi, resolution 0.5 psi, accuracy +/- 1% FS. The inline filter minimum requirements; 1/4" male flare, 40 micron, 250 psi.

Balloon Test Procedure


NOTE: The following should be tested with battery power only (A/C power disconnected) and then tested with A/C power connected.

- Connect an additional 1/4" refrigerant test hose from the service Schrader valve of the PAK assembly (45° depressor connection) to the distribution piping service port (low-loss fitting threaded into hose straight connection). Refer to **Figure 59**.
- Check that the pistons in the PAK and SVAs are still in the set position.
- Remove the nozzle caps from the nozzles.
- Remove hood filters. This will expose the Firestat(s) and the duct and plenum drops.
- Place testing balloons over all nozzles (appliance, duct, and plenum).
- Open the Nitrogen Service Cylinder. Adjust the pressure to 200 psig.

CAUTION!: Supplied Nitrogen Pressure Shall Not Exceed 250 psig Maximum.

- Place the system in "Armed" mode.
- Lift the cover to the manual activation device and "push" to activate the fire system. Refer to **Figure 60**.
- When testing with A/C power, verify the Electrical Control Package (ECP) has activated. The audible alarm will sound, and the system is in a fire condition. The HMI will flash FIRE on the screen.
- Verify the PAK and all SVAs have actuated. The piston should be fully extended and in a locked position. Refer to **Figure 60**.
- Verify that there are no leaks in the actuation line, except through the vent limiting orifice.
- Verify that the solenoid is in the energized state.
- Verify all balloons are filled.
- Verify fuel to all appliances under the protected hood has shut off.
- Verify the makeup air supplied to the hood has shut off.
- If all of the above is confirmed, reset the control panel. The manual activation device can be reset by twisting the push button in a clockwise motion. Press the "Push To Reset" button. Refer to **"Reset Overview"** on page 56.
- Close the Nitrogen Cylinder. Remove all balloons from the nozzles.



Figure 59 - Additional 1/4" Test Hose




1. Schrader service valve of the PAK assembly
 2. 1/4" Refrigerant Test Hose (Short)
 3. Low-loss Fitting Straight Adapter
 4. Distribution Piping Service Port
- Additional hoses/lengths required for servicing.**

Figure 60 - Balloon Test

Manual Activation Device (MAD)



1. PAK Actuated
2. SVA Actuated



Firestat Test Procedure


NOTE: The following should be tested with battery power only (A/C power disconnected) and then tested with A/C power connected.

ATTENTION: You do not need nitrogen for this test.

CAUTION!: The use of a torch or flame is strictly prohibited.

- Use a portable heat source to apply heat to the duct Firestat in accordance with the manufacturer's instructions. Please refer to applicable detector manufacturer's manual. Refer to **Figure 61**.
- When the Firestat's heat set point is reached, the fire system will activate. Some residual nitrogen from the test cylinder may release.
 - When performing this test with battery power only, check the CORE-board fire status light.
 - When performing this test with A/C power, the exhaust fan will activate. Depending on the hood lights activation setting, they will turn on or off.
- Check all Firestats in the system.
- After the system is tested, install nozzle caps, and install hood filters.

Figure 61 - Firestat Riser Location



- 1. Firestat
- 2. Heat Gun
- 3. Deflector

Disconnecting Service Cylinder Tank

- Place the TANK fire system into "Test" mode.
- Relieve pressure from the Nitrogen Cylinder.
 - Cylinder assemblies with one Schrader valve:
 - Slowly disconnect the inline filter from the PAK hose.
 - Cylinder assemblies with dual Schrader valves:
 - Check all cylinder gauges to confirm proper pressure is within the "green" range. If pressure is low, refer to **"Adding Nitrogen to Tank(s)" on page 74**.
 - Slowly disconnect the test hose with inline filter from the tank cylinder.
- Relieve pressure in the actuation line. Slowly disconnect the test hose from the PAK service valve.
- Disconnect the test hose from the fire system distribution piping service port. Remove low-loss fitting adapter.

Re-arming System


- Reset each PAK and any SVAs by pushing the spring-loaded pin on the piston. Press the piston into the body of the actuator.
- Verify residual pressure is relieved at Schrader valve.

NOTE: If a PAK/SVA fails to operate or cannot be properly reset, the unit must be replaced. Refer to page 73 for replacement procedures.

- Verify all of the actuation lines between the PAK and SVA(s) are secure and tight. Place Schrader valve cap on the fire system distribution piping service port.
- Check all cylinder gauges to confirm proper pressure is within the "green" range. If pressure is low, add nitrogen. Refer to **"Adding Nitrogen to Tank(s)" on page 74**.
- Re-arm the control panel by placing the package in "Armed" mode.

Figure 62 - Resetting PAK/SVA(s)

- 1. PAK in Ship/Test Position
- 2. SVA in Ship/Test Position
- 3. Distribution Piping Service Schrader Valve
- 4. Primary Actuator Hose
- 5. Actuator Activated
- 6. Actuator Set Position



NOTE: Tanks should never be filled with agent in the field.

Leakage Testing

- Connect a 1/4" pressure gauge to the Schrader service valve of the PAK assembly. Verify the pressure reads 0 psi. Refer to **Figure 63**.
- Prepare the tank cylinder assembly for leakage testing.
 - Cylinder assemblies with one Schrader valve:
 - Inspect the PAK hose O-ring. Replace O-ring if damaged or deformed. Refer to **"TANK FIRE SUPPRESSION SYSTEM PARTS" on page 83**.
 - Quickly connect the PAK hose to the Schrader valve on the primary cylinder to minimize nitrogen loss.
 - Cylinder assemblies with dual Schrader valves:
 - Place Schrader cap back on the tank cylinder secondary Schrader valve.

NOTE: PAK hoses with knurled fitting must ONLY be tightened by hand and not with a tool. If the PAK hose with a hex fitting was loosened for any reason, this fitting must be torqued to 15 in-lbs.


- Monitor the pressure gauge on the PAK. The pressure must not read above 0.5 psi for 15 minutes. This indicates the solenoid is in the de-energized state and will not let pressure through as intended. The gauge may fluctuate between 0 and 0.5 psi.

CAUTION!: If pressure reads above 0.5 psi, immediately remove the primary actuator hose from the primary tank. Submit a ticket to through technical support. Refer to "Technical Support Information" on page 84.

- Verify that the pistons in the PAK and SVAs are in the set position and not actuated. Refer to **Figure 62 on page 69**.

Figure 63 - Leakage Test Setup


1. PAK Reset and in the Ship/Test Position
2. SVA Reset and in the Ship/Test Position
3. PAK Hose Connected to Tank
4. Digital Pressure Gauge



- Install the PAK and any SVAs onto their respective cylinders. Refer to **Figure 64**.
- Remove the pressure gauge on the PAK. Place the Schrader valve cap back onto the service port of the PAK assembly. Tighten the cap.
- Spray the primary charge hose connection with a micro leak detector to check for leaks.
- Verify that the Supervisory Pressure Switches have reset per the control panel manual instructions.
- The system should be in the "Armed" position, and no faults should be active on the HMI when finished testing.

Figure 64 - PAK/SVA(s) Installed

1. PAK Installed
2. Schrader Cap
3. SVA Installed



MAINTENANCE

NOTE: It is the responsibility of the system installer to review system operation and owner obligations, and to provide any necessary literature to the owner at the time of system installation.

This section contains the inspection and maintenance instructions for the TANK Fire Suppression extinguishing system. These procedures must be performed in accordance with NFPA 17A and the National Fire Code of Canada as applicable. If problems arise, corrective action must be taken.

Every Month (System Owner)

Refer to the cylinder nameplate for proper inspection and maintenance instructions. Inspections are required to ascertain that the system is operable and that no changes have occurred, which would compromise the effectiveness of the system. A record of the monthly inspection is to be kept reflecting the date inspected, initials of the person performing the inspection, and any corrections required. If any discrepancies are noted while making this inspection, **DO NOT CONTINUE OPERATING COOKING APPLIANCES**. Immediately contact a factory trained distributor for service and/or repair.

The following procedure is to be performed by the Owner of the system on a monthly basis:

Table 20 - Owner's Monthly Maintenance

Checkbox	Procedure
	Verify the extinguishing system is in its proper location.
	Inspect all system components, agent distribution pipe, and conduit runs for physical damage and/or displacement.
	Inspect all nozzles caps are in place and intact. Check for possible obstructions to the discharge of the wet chemical.
	Inspect each Cylinder and Valve Assembly. The indicator on the pressure gauge should be in the "green" range (200 psig). The cylinder should not show evidence of corrosion or damage.
	Verify that manual release stations are unobstructed and in clear view and are labeled for intended use.
	Verify all tamper seals are intact, and the system is in a ready condition.
	Verify the inspection tag or certificate is in place and current.
	Verify the hood, duct, and protected cooking appliances have not been replaced, modified, or relocated.

Every Six Months (Factory Trained Distributor)

All systems shall be inspected and serviced semi-annually by a factory trained distributor.

1. Place the control panel in “Test” mode and ensure there are no supervision faults, refer to **“Reset Overview” on page 56**.
2. Verify that the system design and installation are adequate to protect the hazard area and conform to the instructions in this manual. Check the following:
 - All equipment requiring fire protection within the hazard area is protected.
 - There have been no unauthorized alterations to the protected area or equipment, or to the wet chemical system.
 - All cylinder mounting brackets are securely fastened to the hood.
 - Verify all cylinders are pressurized within the “green” range.
 - Check hose connections with soapy water to check for leaks.
 - All nozzles are properly aimed, secured, and located within the proper distance from the protected equipment. Each nozzle should be clean and equipped with a cap.
 - All piping joints and pipe supports are securely fastened.
 - The pipe lengths, sizes, fittings, and material are as specified in this manual.
 - All wiring is in compliance with local codes.
 - All field wiring is free of ground fault or short-circuit conditions.
 - All system components and installation material are as specified in this manual.
3. Perform Start-up/Test Procedure. Refer to **“START-UP/INSPECTION TEST PROCEDURE” on page 65**.

NOTE: For Pollution Control Units (PCU) with a TANK Fire Suppression system, a balloon test is not required. When actuating the system, to verify the system discharges properly, listen or feel for the flow of nitrogen through all the nozzles in the PCU.

Every Two Years

1. Replace batteries. The replacement battery part number is PS-1270-F2; two are required. Once the battery is disconnected, the connected equipment is not protected from power outages. The new battery must be installed immediately. Refer to the replacement battery installation guide for more details.
2. Inspect the condition of all wires and plumbing. Plumbing should be free of corrosion, and wire insulation must be in good condition.

Every Twelve Years

The 12-year maintenance is typically done in conjunction with the semi-annual maintenance. These procedures shall be performed in addition to the tests conducted at Semi-Annual intervals. Refer to “Every Six Months (Factory Trained Distributor)”.

Decommissioning

If it should become necessary to disconnect the CORE system from AC power for an extended period of time (more than 2 days), the batteries should be disconnected to prevent them from being damaged due to complete discharge.

Agent Cylinder Tanks

Each cylinder must be replaced every 12 years. For information on replacing cylinders, refer to **“POST-DISCHARGE MAINTENANCE” on page 75**.

Actuation Hoses

All actuation hoses must be hydrostatically tested (at 500 psi test pressure) or replaced every 12 years in accordance with NFPA 17A.

Conditional Maintenance

Replacing A Primary Actuation Kit

If a PAK fails to operate during system testing, follow these steps to replace the PAK:

1. Ensure the primary actuation hose is not connected to the primary cylinder or a nitrogen pressure supply system.
2. Remove the supervisory pressure switch installed on the PAK.
3. If applicable, disconnect the secondary actuation hose from the PAK.
4. Loosen the PAK shipping bolts from the top of the bracket, slide the unit back and remove it from the bracket.
5. Loosen the shipping bolts on the new PAK. Slide the unit into the bracket. Tighten the shipping bolts to ensure the PAK is held firmly but can still be slid back for installation to the cylinder valve.
6. If applicable, remove the side vent limiting orifice on the PAK and install in the secondary actuation hose.
7. Install the supervisory pressure switch onto the new PAK.

Replacing A Secondary Valve Actuator

If an SVA fails to operate during system testing, follow these steps to replace the SVA:

1. Ensure the primary actuation hose is not connected to the primary cylinder or a nitrogen pressure supply system.
2. Disconnect any secondary actuation hose connecting the SVA to the PAK or other SVAs.
3. Loosen the SVA shipping bolts from the top of the bracket, slide the unit back and remove it from the bracket.
4. Loosen the shipping bolts on the new SVA. Slide the unit into the bracket. Tighten the shipping bolts to ensure the SVA is held firmly but can still be slid back for installation to the cylinder valve.
5. If applicable, remove the side vent limiting orifice(s) on the SVA and connect the SVA to any applicable secondary actuation hoses.

Adding Nitrogen to Tank(s)

NOTE: Verify the pressure loss is not due to a discharge or unknown issue. Spray the pressurized PAK, SVA, and tank cylinder assemblies (PAK hose connection and pressure switches) at all fittings with a micro leak detector. Repair or replace components that show signs of leaking/damage.

Table 23 on page 83 provides all required components/part numbers to service low pressure tank(s). Refer to **Figure 65** for assembling service kit. After the low pressure condition is identified and fixed, follow these steps to add nitrogen.

- Place the system in “Test” mode.
- Unbolt PAKs/SVAs from tank(s) and secure to tank bracket.
- Determine TANK Schrader valve ports. Refer to **Figure 65**.
 - Cylinder assemblies with one Schrader valve, disconnect the PAK hose from the primary Schrader valve, if already connected.
 - Cylinder assemblies with dual Schrader valves, remove Schrader cap from the secondary Schrader valve.
- Connect a Nitrogen Service Cylinder via the 1/4” refrigerant test hoses with an inline filter to the 1/4” to the Schrader valve fill port.
- If the filter has a directional airflow arrow, verify correct orientation. Arrow should be pointing away from the nitrogen tank and toward the fire system tank.

CAUTION!: Supplied Nitrogen Pressure Shall Not Exceed 250 psig Maximum.


- Open the Nitrogen Service Cylinder. Adjust the pressure to 225 psig.
- Pressurize the tank to 200 psig. The green indicator range is 175 to 225 psig.
- Close the Nitrogen Service Cylinder.
- Remove test hoses from the Schrader valve.
- Prepare tanks for final connections.
 - Cylinder assemblies with one Schrader valve, connect the PAK hose to the primary Schrader valve.
 - Cylinder assemblies with dual Schrader valves, place the Schrader cap on the secondary Schrader valve.
- Verify PAK/SVA are still in the set position.
- Remove PAKs/SVAs from the tank bracket and secure to the tanks. Tighten hardware.
- Connect a 1/4” pressure gauge to the Schrader service valve of the PAK assembly. Pressure should read 0 psi.
- Spray the pressurized system components and fittings with micro leak detector. Monitor the pressure gauge on the PAK. The pressure must not read above 0.5 psi for 15 minutes. Pressure may fluctuate between 0 - 0.5 psi.

CAUTION!: If pressure reads above 0.5 psi. Submit a ticket to through technical support. Refer to “Technical Support Information” on page 84.

- Place the system in “Armed” mode.
- Finalize Start-up/Test procedure. Continue to **“START-UP/INSPECTION TEST PROCEDURE” on page 65.**

Figure 65 - Service Kit Set-up

1. Nitrogen Service Cylinder
2. Pressure Regulator
3. 1/4” Refrigerant Test Hose (60” Long)
4. 1/4” Male to Male Inline Filter
5. 1/4” Refrigerant Test Hose (36” Long)
6. Digital Pressure Gauge
7. Primary Schrader Valve (Single Schrader Port)
8. Secondary Schrader Valve (Dual Schrader Port)
9. PAK Hose (Connected to TANK)



POST-DISCHARGE MAINTENANCE

General Information

Liquid Fire Suppressant, the Aqueous Potassium Carbonate (APC) base wet chemical used in the TANK Fire Suppression extinguishing system, is non-toxic. However, any food or cooking oils that have been contaminated with wet chemical agent should be discarded. Refer to Safety Data Sheet (SDS).

After any system discharge, it is best to clean the area as soon as it is safe to do so. Prolonged exposure of equipment to wet chemical can result in localized corrosion due to moisture in the air. Clean up should be completed within 24 hours of any system discharge.

TANK Fire Suppression cylinders need to be replaced every 12 years, and after any system discharge.

Appliance Cleanup

No unusual cleanup procedure is required. The reaction of the wet agent and the grease is one of saponification, and it produces a foam that can be wiped off. After the appliances have completely cooled, the residue from the discharge may be cleaned up using a wet cloth or sponge. Ensure that all fuel and electric power to the area has been shut down. Wear rubber gloves and eye protection while cleaning. If skin or eyes come in contact with the agent, flush thoroughly with water.

WARNING!

Do not disturb the foam until the cooking appliances, plenum, and duct have cooled sufficiently. Do not put water on hot grease as this will cause violent steaming and spattering.

WARNING!

APC wet agent is electrically conductive. To avoid electrical shock, de-energize all electric circuits to appliances, outlets, and wiring by disconnecting or turning off the electric power at the main fuse or circuit breaker box. Do not cleanup APC wet agent or touch electric appliances, outlets, power cords, or other wiring with electric power on.

Cleaning Distribution System

The TANK Fire Suppression extinguishing system must have all discharge piping and nozzles flushed out with water after any discharge, as detailed in the following procedures.

Cleaning Nozzles

1. Remove all nozzles from the system.
2. Inspect each nozzle & filter and remove any debris.
3. Clean nozzle and vane by flushing thoroughly with warm soapy water. Remove any foreign matter that could impede flow.
4. Run water through the nozzle tip to ensure the orifice is not clogged.
5. Thoroughly dry nozzles with dry air or nitrogen and set aside.

Flushing the Distribution Pipe Network

Before starting the flushing procedure, inspect the complete piping network, and replace any pipe or fittings that have been subjected to direct flame or excessive heating. The following procedure describes flushing the pipe network with a spare/test cylinder. The pipe network can also be flushed utilizing an external water supply if available.

Flushing Procedure with Spare/Test Cylinder

- Check the pressure gauge on each cylinder to ensure it has been depressurized.
- Clean the area with warm soapy water, and rinse with water. Dry thoroughly with dry air or nitrogen.
- Disconnect the Primary Actuator Kit (PAK) stainless steel hose from the primary cylinder valve.
- Remove all cylinders from the system. Refer to **“Removing a Cylinder Tank (Empty or Storage)” on page 79.**
- Fill test cylinder(s) with water and pressurize.
- Install a test cylinder for each removed cylinder. Refer to **“Installing New Cylinder Tank(s)” on page 80.**
- Attach a suitable container (or hose to a container or other point of disposal) at each pipe outlet where a nozzle was installed to collect the water discharge.
- Install the PAK and SVAs onto their respective cylinders.
- Re-arm the control panel by placing the package in “Armed” mode.
- Connect the primary actuator hose securely to the Schrader valve on the primary cylinder.

NOTE: PAK hoses with knurled fitting must ONLY be tightened by hand and not with a tool. If the PAK hose with a hex fitting was loosened for any reason, this fitting must be torqued to 15 in-lbs.

- Activate the system using the manual activation device.
- Once the system is fully discharged of water, reset the system. Refer to **“Reset Overview” on page 56.**
- Remove containers or hoses from all nozzle location pipe outlets.
- Remove test cylinders.
- Connect a nitrogen service tank to system piping service port and blow out the discharge piping to remove all excess water. Disconnect the nitrogen service tank. Refer to **“Dry the Lines” on page 78.**
- Install new cylinders at each location. Refer to **“Installing New Cylinder Tank(s)” on page 80.**
- Re-install nozzles, ensuring that all nozzles are in the correct location and properly aimed.
- Complete the Start-up/Test Procedure. Refer to **“START-UP/INSPECTION TEST PROCEDURE” on page 65.**

NOTE: Tank cylinder(s) should never be filled in the field with agent.

Flushing Procedure with an External Water Supply

The procedure is used for flushing out the fire system piping after a fire system discharge. **Tank cylinder(s) must be in place when flushing the system.** Refer to **Figure 66** for testing setup.


Parts:

- Tank Flushing Adapter
- Bucket Support Bracket
- Buckets
- Water Hose
- Nitrogen Service Kit
- Silicone Lubricant
- 1/4" SAE Tee Connector with cap and valve core. 1/4" female knurl and 1/4" SAE male connections. Used for multiple manifold systems only.

Flush the System

- Remove the appliance nozzle that is furthest away from the utility cabinet.
- Use a 3/8" to 3/4" flushing adapter to attach the hose to the nozzle drop. Attach a water hose to the flushing adapter and the other end to a water source.
- Hang the bucket support brackets and buckets on the applicable drops. If possible, connect a hose to the grease spout and route the hose to the nearest floor drain.
- Flush with water for a minimum of one minute. Larger systems will take longer than a minute.

Figure 66 - Flushing System with External Water Supply




- | | |
|---|--------------------------|
| 1. Nozzle Furthest from Utility Cabinet | 5. External Water Supply |
| 2. 3/8" to 3/4" Tank Flushing Adapter | 6. Water Hose |
| 3. Bucket Support Bracket | 7. Utility Cabinet |
| 4. Buckets | |

- Remove flushing adapter. Reinstall the nozzle and hang a bucket.
- When reinstalling nozzles, ensure that all nozzles are in the correct location and properly aimed.

Dry the Lines

- Connect the nitrogen line directly to the distribution piping service Schrader valve on the manifold line. Refer to **Figure 67**.
- Set your pressure regulator to 100 psi and blow down the lines for a minimum of 30 seconds. Larger systems may take longer.

Figure 67 - Connecting Nitrogen to Dry Lines



- Remove nitrogen line from the distribution piping service Schrader valve.
- Remove all hoses and buckets.
- Install nozzle caps on nozzles.

Cylinder Tank Maintenance

TANK Fire Suppression cylinders need to be replaced every 12 years, and after any system discharge.

WARNING!

Never assume that a cylinder is unpressurized. Handle all cylinders as if they are pressurized until verified otherwise. Pressurized cylinders are extremely hazardous.

When performing any cylinder maintenance procedure, the cylinder must be properly secured to a rigid structure capable of withstanding the full thrust that would result if the valve were to open inadvertently.

Any time a cylinder assembly is unsecured, the anti-recoil plate must be installed on the valve outlet to provide a safe, controlled discharge in the event of accidental actuation.

Failure to take proper precautions could result in death, serious personal injury and/or property damage.

Removing a Cylinder Tank (Empty or Storage)

- Unbolt the actuators from the tanks and bolt into shipped position. Repeat for all additional actuators.
- Disconnect the PAK hose.


IMPORTANT: If tank(s) will be stored for an extended period, you must prevent debris from entering the system. Cover the discharge outlet (tank) and discharge adapter (system piping). Install the Valve Protection Plate and Anti-recoil Plate onto the cylinder.

- Use a 1/2" and 9/16" box end wrench to remove the cylinder mounting bolts from the bracket.
- Loosen the tank straps, and remove the tank. Repeat for additional tanks.
- For each secondary cylinder, perform the following before moving to the next cylinder:
 - Remove the Supervisory Pressure Switch from the cylinder valve if applicable.
 - Loosen the cylinder bolts holding the valve to the discharge adapter and cylinder bracket.
 - Loosen the tank straps holding the cylinder in place.
- Pull the cylinder out from the bracket. Refer to **Figure 68**.

Figure 68 - Tank Removal Process

1. PAK in Ship/Test Position
2. SVA in Ship/Test Position
3. PAK Hose
4. Secondary Supervisor Pressure Switch (Optional)
5. Cylinder Mounting Bolts
6. Tank Straps


NOTE: Tanks should never be filled with agent in the field.



Installing New Cylinder Tank(s)

- Remove the anti-recoil and valve protection plates.
- Install the tank by fully inserting the tank into the adapter.
- Apply silicone lubricant to the adapter and O-ring to ensure a smooth installation.
- Install and tighten the hardware that hold the tank onto the bracket. The square nut can be tightened with a 9/16" box end wrench; the bolt head can be tightened with a 1/2" box end wrench.
- Tighten the middle tank strap to help support the weight of the tank and to assist in lining up the bolts.
- Tighten all 3 straps.
- Repeat for all other tank cylinder(s) in the system.
- After installing new cylinder, follow **“START-UP/INSPECTION TEST PROCEDURE”** on page 65 procedures to complete an inspection of the system.

Figure 69 - Installing Tank




Depressurizing a Cylinder Tank

WARNING!

Failure to correctly secure the hose could result in death, serious bodily injury, and/or property damage.

1. Secure the cylinder in a chain vice, strap vice, or similar device.
2. Prepare high-pressure discharge hose with a spare nozzle on the end.
3. Remove the anti-recoil plate from the cylinder outlet and install the discharge adapter.
4. Install a ball valve onto the discharge adapter outlet. Refer to **Figure 70**.
5. Attach the discharge hose with nozzle to the ball valve outlet.
6. Attach the hose and discharge adapter assembly to the cylinder valve outlet.
7. Insert the opposite end of the hose into an appropriate container for the wet chemical agent.
8. Ensure that the hose is secure and will not come loose or separate from the container.
9. Install a Secondary Valve Actuator (SVA) onto the cylinder valve.
10. Connect the nitrogen service cylinder to one of the SVA ports, and a SVA vent limiting orifice in the opposite port.
11. Ensure that the ball valve on the discharge assembly is in the closed position.
12. Open the nitrogen supply, slowly increase pressure until the SVA actuates. Turn off nitrogen supply.
13. Carefully open the discharge valve.
14. Monitor the discharge to prevent spillage and to ensure that the hose remains secure.
15. Control the rate of discharge via the ball valve.
16. If applicable, stop the flow and change containers.
17. When the discharge is complete, turn off the nitrogen service cylinder supply.
18. Check that the cylinder gauge indicates no pressure, and carefully depress the Schrader on the cylinder valve. Check for any possible flow/leakage of nitrogen.
19. Slowly disconnect the nitrogen supply, relieving pressure from the SVA.
20. Remove the SVA from the valve.
21. Remove the valve/siphon tube assembly by unthreading the valve counterclockwise from the cylinder.
22. Invert the cylinder to remove any residual wet chemical.
23. Clean the cylinder and threads with warm soapy water and rinse with clean water.
24. Blow out any residual moisture from the cylinder and threads with dry air or nitrogen.

Figure 70 - Cylinder Discharge Assembly



Rechecking the System

After the inspections and procedures described previously in this section, the fire-suppression system is ready to be fully checked out before installation of the replacement wet chemical cylinders.

1. Follow the system commissioning and test procedures outlined in **“START-UP/INSPECTION TEST PROCEDURE” on page 65**.
2. Be sure to check the system for all modes of operation.

Mobile Kitchen/Seasonal Shutdown

Figure 71 provides details on components that require attention when decommissioning/commissioning mobile kitchens or kitchens used for seasonal occasions.

When the kitchen is not in use for an extended period:


1. Verify incoming power to the hood is OFF or DISCONNECTED.
2. Disconnect the battery connection from the CORE Board at connector J1 located inside the control package. Alternatively, you may remove the fuse (5 amp blade fuse) from the battery connector kit.
3. Disconnect the PAK and SVA(s) from the tank(s).
4. Place the PAK and SVA(s) in the ship/test position. Install valve protection plate.

NOTE: If the space drops below -20°F, the tanks must be removed and stored in a conditioned space.

When starting the kitchen backup from an extended shutdown:

1. Verify incoming power to the hood is OFF or DISCONNECTED.
2. Verify the PAK and SVA(s) are in the set position.
3. Install the battery connection to the CORE Board at connector J1. If the fuse (5 amp blade fuse) is removed, install fuse to the connector kit at the batteries. If a replacement connector kit is required, order part number - CORECONKIT12. If replacement batteries are required (12V, 7AH,.250 terminals, AGM), order part number - PS-1270-F2 (must order two).
4. Check the pressure gauge is in the “green” range. If the pressure is low, refer to **“Adding Nitrogen to Tank(s)” on page 74**. If the tank(s) were removed for storage, install the tank(s).
5. Restore incoming power to the hood.
6. Remove the valve protection plate. Place the PAK and SVA(s) in the installed position. Refer to **“START-UP/ INSPECTION TEST PROCEDURE” on page 65** to finish start-up.

Figure 71 - Actuator and Battery/Fuse Details



TANK FIRE SUPPRESSION SYSTEM PARTS

Table 21 - System Components

Description	Part Number
TFS Cylinder Assembly, Filled & Pressurized	87-300001-001
Bracket, TFS Cylinder	TFS-UCTANKBRACKET
Discharge Adapter	WK-283952-000
Discharge Adapter Tank Locking Plate	DATANKLOCK
O-Ring for Discharge Adapter	WK-108019-000
Primary Actuator Kit (PAK)	87-300030-001
O-ring 1/4" PAK Hose - Hex Fitting	PAKHOSEORING
Secondary Valve Actuator (SVA)	87-120042-001
Secondary Valve Actuator Hose 7"	87-120045-001
Secondary Valve Actuator Hose 24"	87-120045-002
Secondary Valve Actuator Hose 60"	87-120045-003
Cylinder Supervisory Pressure Switch	87-300040-001
Vent Limiting Orifice	12A06
Gas Shut-off Valve, 3/4" (ASCO)	8214235
Gas Shut-off Valve, 1" (ASCO)	8214250
Gas Shut-off Valve, 1-1/4" (ASCO)	8214265
Gas Shut-off Valve, 1-1/2" (ASCO)	8214275
Gas Shut-off Valve, 2" (ASCO)	8214280
Gas Shut-off Valve, 2-1/2" (ASCO)	8214290
Gas Shut-off Valve, 3" (ASCO)	8214240

Table 22 - Maintenance Components

Description	Part Number
Valve Protection Plate	WK-255096-000
Anti-Recoil Plate	WK-255681-000
Discharge Adapter Kit (includes mounting flange)	83-844908-000
Schrader Cap (used with valve for test and service ports)	87-300140-001
Schrader Valve (used for test and service ports)	87-300141-001
SVA bolts	87-300152-001
Balloons	ADRITE11IN
Bucket Support Bracket	BUCKSUP

Table 23 - Service Parts (not supplied with system)

Description	Part Number
TANK Fire Suppression Service Kit (Individual Parts Below)	TANK Fire Suppression-S-Kit
Fitting 1/4" Male to Male Thread Union	U24
Low-Loss Fitting 1/4" Straight Adapter Male to Female Thread	NABS
1/4" Refrigerant Test Hose, 36" Long	NHD1436
1/4" Refrigerant Test Hose, 60" Long	NHD1460
O-ring Replacement for 1/4" Refrigerant Test Hose	19020
Nitrogen Service Cylinder (Ships empty)	HP20
Pressure Regulator	GEN450F
Inline Refrigerant Filter	C-032
Digital Pressure Gauge	Varies

CLEANING AND MAINTENANCE RECORD

[illegible]

As a result of our dedication to constant improvements and quality, the MANUFACTURER reserves the right to update specifications without notice. Please refer to MANUFACTURER'S website for up to date documentation.

Technical Support Information

CASLink



Technical Support



Parts Store

