



**LEGEND**

- AC AUTOMATIC CUTOUT
- MC MANUAL CUTOUT
- DS DISCONNECT SWITCH
- CONTACTOR COIL
- HEATING ELEMENT
- TR TRANSFORMER
- CONTACT NORMALLY OPEN
- FUSE

**WARNING:**  
Disconnect all supplies before working on this duct heater

**IMPORTANT:**  
Wire in according with electrical codes  
Use copper wire for 90°C minimum

**NOTE:**  
All wiring outside this frame are wiring by others

**National Environmental Products Ltd** 400 Lebeau, Montreal (QC) H4N 1R6  
T: (514) 333-1433 F: 333-3163

PROPRIETARY INFORMATION : THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION & IT'S PROPERTY OF N.E.P. LTD. THIS DOCUMENT AND THE INFORMATION IT CONTAINS SHALL NOT BE DUPLICATED OR USED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF N.E.P. LTD.

**ELECTRICAL DRAWING**

**PART NUMBER:** RTUEC1L-60KW4803  
**PROJECT NAME:** RTUEC  
**CUSTOMER NAME:** CAPTIVE AIRE, INC.